



**MOTOFAN**  
 ul. Bojanowskiego 8  
 63-820 Piaski

mobile: +48 501 589 078  
 fax: +48 65 571 90 23

[www.motofan.pl](http://www.motofan.pl)  
 e-mail: [darek@motofan.pl](mailto:darek@motofan.pl)

Firma MOTOFAN od lat specjalizuje się w dostawach filtrów powietrza, oleju, paliwa, kabinowych, hydraulicznych dla motoryzacji, sprzętu ciężkiego, rolnictwa, przemysłu. Przez ten czas zdobyliśmy rzeszę wielu zadowolonych klientów. Poniżej prezentujemy wykaz filtrów pasujących do maszyn marki CASE, który w większości prezentujemy wraz z numerami oryginalnymi.

Zapraszam do zapoznania się z wykazem i kontaktu z nami.

Marka	Model	Silnik	Model silnika	Typ filtra	Numer OE	Numer OE1	Opcja
Case IH	45			Lube	A44081	A44081	
Case IH	45			Air, Outer	S231996	S231996	S/N-- 6295304-6295604
Case IH	45			Air, Inner	S238647	S238647	S/N-- 6295605 & After
Case IH	45			Air, Outer	S238646	S238646	S/N-- 6295605 & After
Case IH	45			Air, Outer	S222020	S222020	To S/N-6295304
Case IH	45			Fuel Filter	A43344	A43344	Injection Pump
Case IH	45			Fuel Filter	A46045	A46045	Kit
Case IH	45			Hydraulic	S140005	S140005	
Case IH	45			Hydraulic	S233969	S233969	
Case IH	45			Hydraulic	S202018	S202018	Suction
Case IH	45			Hydraulic	S200193	S200193	Torque Converter
Case IH	60			Hydraulic	H340047	H340047	
Case IH	115			Lube	P850589	P850589	
Case IH	115			Air, Inner	A43657	A43657	
Case IH	115			Air, Inner	P850561	P850561	
Case IH	115			Air, Outer	A43656	A43656	
Case IH	115			Air, Outer	S231996	S231996	
Case IH	115			Fuel	P400564	P400564	
Case IH	115			Fuel Filter	P50537	P50537	Tank
Case IH	115			Hydraulic	C1050527	C1050527	
Case IH	115			Hydraulic	P250574	P250574	
Case IH	115			Hydraulic	P1050527	P1050527	Return
Case IH	150			Lube	T40475	T40475	

Case IH	150		Air, Outer	D48198	D48198	
Case IH	150		Hydraulic	D73743	D73743	S/N-- 2025 ON
Case IH	150		Hydraulic	T40403	T40403	To S/N-2025
Case IH	300		Lube	P2050575	P2050575	
Case IH	300		Cab Air	S105531	S105531	Heater
Case IH	300		Air, Inner	P850569	P850569	Heavy Duty Engine
Case IH	300		Air, Outer	P850568	P850568	Heavy Duty Engine
Case IH	300		Fuel	P1050595	P1050595	
Case IH	300		Fuel Filter	P850566	P850566	Tank
Case IH	300		Hydraulic	P1050531	P1050531	
Case IH	300		Hydraulic	P400580	P400580	
Case IH	310		Lube	A36206	A36206	
Case IH	320		Lube	A36206	A36206	
Case IH	320		Lube	G45008	G45008	Diesel Only
Case IH	320		Fuel	A57228	A57228	Diesel Only
Case IH	320		Hydraulic	G20203	G20203	
Case IH	325		Lube	366700A1	366700A1	
Case IH	325		Air	8900119925	8900119925	Outer Air
Case IH	325		Air	8900119926	8900119926	Inner Air
Case IH	325		Fuel	J930942	J930942	Primary Fuel
Case IH	325		Fuel	J931063	J931063	Secondary Fuel
Case IH	325		Hydraulic	8960940011	8960940011	
Case IH	325		Transmission	3322202A1	3322202A1	
Case IH	325		Coolant	J100304	J100304	
Case IH	330		Lube	366700A1	366700A1	Before HHD0000242
Case IH	330		Lube	8900131282	8900131282	After HHD0000242
Case IH	330		Fuel	8900127093	8900127093	Before HHD0000242
Case IH	330		Fuel	8900131285	8900131285	After HHD0000242
Case IH	330		Fuel	8900129805	8900129805	After HHD0000242
Case IH	330		Air	8900119925	8900119925	Outer Air
Case IH	330		Air	8900119926	8900119926	Inner Air
Case IH	330		Hydraulic	8960940011	8960940011	
Case IH	330		Transmission	3322202A1	3322202A1	
Case IH	330		Coolant	J183318	J183318	
Case IH	350		Lube	A306696	A306696	
Case IH	350		Air, Outer	D48198	D48198	
Case IH	350		Fuel Primary	A402081	A402081	KitS/N-- 2718490 After
Case IH	350		Fuel Primary	A35863	A35863	Prior To S/N-2718490
Case IH	350		Fuel Secondary	A52046	A52046	Prior To S/N-2718490
Case IH	350		Hydraulic	D75831	D75831	
Case IH	360	Diesel	Air, Inner	A603291	A603291	
Case IH	360	Diesel	Air, Outer	H436540	H436540	
Case IH	360	Diesel	Air, Inner	A603290	A603290	Diesel
Case IH	360	Diesel	Air, Outer	D48198	D48198	Gas
Case IH	360	Diesel	Hydraulic	H335620	H335620	Return

Case IH	360		Diesel	Hydraulic	N9025	N9025	Suction	
Case IH	400			Lube	P2050575	P2050575		
Case IH	400			Cab Air	S105531	S105531		
Case IH	400			Air, Inner	P850569	P850569	Heavy Duty Engine	
Case IH	400			Air, Outer	P850568	P850568	Heavy Duty Engine	
Case IH	400			Fuel	P1050595	P1050595		
Case IH	400			Fuel	P850566	P850566	Tank	
Case IH	400			Hydraulic	P400580	P400580		
Case IH	400		Diesel	Lube	G45008	G45008		
Case IH	400		Diesel	Fuel	A57228	A57228		
Case IH	425			Lube	A7820	A7820		
Case IH	425			Fuel	A57228	A57228		
Case IH	425			Fuel	A7627	A7627	Secondary	
Case IH	425			Hydraulic	A27460	A27460		
Case IH	430		Diesel	Lube	A306696	A306696	S/N-- 8262800-8297800	
Case IH	430		Diesel	Fuel	A52046	A52046		
Case IH	430		Diesel	Fuel	73671	73671	Injection Pump	
Case IH	430		Diesel	Fuel Primary	A35863	A35863	S/N-- 8260341-On	
Case IH	430		Diesel	Fuel Primary	A22001	A22001	To S/N-826034	
Case IH	430		Diesel	Hydraulic	A39578	A39578		
Case IH	430		Diesel	Hydraulic	G20203	G20203		
Case IH	430		Diesel	Hydraulic	A10059	A10059	Pump	
Case IH	430		Diesel	Hydraulic	A42242	A42242	S/N-- 8297801-On Steering	
Case IH	450		207	Lube	A306696	A306696		S/N 3060306-ON
Case IH	450		207	Air, Outer	A42274	A42274		S/N 3060306-ON
Case IH	450		207	Fuel	A402081	A402081	Kit	S/N 3060306-ON
Case IH	450		207	Hydraulic	D75831	D75831		S/N 3060306-ON
Case IH	450		207	Hydraulic	A65854	A65854	Pressure	S/N 3060306-ON
Case IH	450		207	Hydraulic	A65854	A65854	Suction	S/N 3060306-ON
Case IH	460		Diesel	Lube	205282A1	205282A1		
Case IH	460		Diesel	Lube	205251A1	205251A1	Oil Screen	
Case IH	460		Diesel	Air, Inner	A603290	A603290		
Case IH	460		Diesel	Air, Outer	A603290	A603290		
Case IH	460		Diesel	Air, Outer	2065510C1	2065510C1	Diesel	
Case IH	460		Diesel	Air, Outer	D48198	D48198	Gas	
Case IH	460		Diesel	Fuel	J843760	J843760		
Case IH	460		Diesel	Fuel In-Line	D209225	D209225	In-Line	
Case IH	460		Diesel	Hydraulic	D206922	D206922	Return/Charge	
Case IH	475		301B	Lube	A306696	A306696		
Case IH	475		301B	Air, Outer	A40866	A40866		
Case IH	475		301B	Fuel	A43344	A43344	Injection Pump	
Case IH	475		301B	Fuel	A46045	A46045	Kit	
Case IH	475		301B	Hydraulic	R25844	R25844		
Case IH	475		301B	Hydraulic	A65854	A65854	Pressure Line	

Case IH	475		301B	Hydraulic	D37035	D37035	Suction Line	
Case IH	475		301B	Hydraulic	D33557	D33557	Tank	
Case IH	475		336	Fuel	A46045	A46045		
Case IH	475		336	Fuel	A43344	A43344	Injection Pump	
Case IH	475		336	Hydraulic	D37035	D37035	Suction	
Case IH	475		336	Hydraulic	D33557	D33557	Tank	
Case IH	520		Diesel	Lube	G45008	G45008		
Case IH	520		Diesel	Fuel	A57228	A57228	In-Line	
Case IH	530		Diesel	Fuel	A52046	A52046		S/N 8212357-ON
Case IH	530		Diesel	Fuel	73671	73671	Injection Pump	S/N 8212357-ON
Case IH	530		Diesel	Fuel	A35863	A35863	Primary	S/N 8212357-ON
Case IH	530		Diesel	Hydraulic	A39578	A39578		S/N 8212357-ON
Case IH	530		Diesel	Hydraulic	G20203	G20203		S/N 8212357-ON
Case IH	530		Diesel	Hydraulic	A42242	A42242	S/N-- 8297801-On Steering	S/N 8212357-ON
Case IH	550			Lube	J908650	J908650		
Case IH	550			Air, Inner	A603291	A603291		
Case IH	550			Air, Outer	A603290	A603290		
Case IH	550			Fuel/Water Separator, Primary	A77470	A77470	1991-ON	
Case IH	550			Fuel/Water Separator	J912020	J912020	4.4 IN	
Case IH	550			Fuel	J903410	J903410	Primary	
Case IH	550			Fuel	J903640	J903640	Secondary	
Case IH	550			Hydraulic	N9025	N9025		
Case IH	550			Hydraulic	D37035	D37035	Suction	
Case IH	550	Cummins	4BT3.9	Lube	A36206	A36206		
Case IH	550	Cummins	4BT3.9	Lube	J908650	J908650		
Case IH	550	Cummins	4BT3.9	Air, Inner	A603291	A603291		
Case IH	550	Cummins	4BT3.9	Air, Outer	A603290	A603290		
Case IH	550	Cummins	4BT3.9	Fuel/Water Separator, Primary	A77470	A77470	1991-ON	
Case IH	550	Cummins	4BT3.9	Fuel/Water Separator	J912020	J912020	4.4 IN	
Case IH	550	Cummins	4BT3.9	Fuel	J903410	J903410	Primary	
Case IH	550	Cummins	4BT3.9	Fuel	J903640	J903640	Secondary	
Case IH	550	Cummins	4BT3.9	Hydraulic	G20203	G20203		
Case IH	550	Cummins	4BT3.9	Hydraulic	N9025	N9025		
Case IH	550	Cummins	4BT3.9	Hydraulic	D37035	D37035	Suction	
Case IH	560			Lube	206385A1	206385A1		
Case IH	560			Lube	205199A1	205199A1	Oil Screen	
Case IH	560			Air, Inner	3140569R2	3140569R2		
Case IH	560			Air, Outer	2065510C1	2065510C1		
Case IH	560			Fuel	J843760	J843760		
Case IH	560			Fuel	D209225	D209225	In-Line	
Case IH	560			Hydraulic	D206922	D206922	Return/Charge	
Case IH	560			Gasket	D37976	D37976		

Case IH	590		Lube	J908650	J908650	
Case IH	590		Air, Inner	A603291	A603291	
Case IH	590		Air, Outer	A603290	A603290	
Case IH	590		Cab Air	R53519	R53519	
Case IH	590		Fuel	D305357	D305357	In-Line
Case IH	590		Hydraulic	D309921	D309921	
Case IH	590		Hydraulic	N9025	N9025	Transmission
Case IH	600	Cummins	Hydraulic	P1050531	P1050531	Transmission
Case IH	600	Cummins	Hydraulic	P1050532	P1050532	Transmission
Case IH	600	Cummins	Hydraulic	P2050553	P2050553	Transmission
Case IH	600	Cummins	Hydraulic	P2050555	P2050555	Transmission
Case IH	600	Cummins	Hydraulic	P2050561	P2050561	Transmission
Case IH	600	Cummins	Hydraulic	P2050562	P2050562	Transmission
Case IH	600	Cummins	Hydraulic	P2050579	P2050579	Transmission
Case IH	600	Cummins	Hydraulic	P850566	P850566	Transmission
Case IH	600	Cummins	Hydraulic	P850568	P850568	Transmission
Case IH	600	Cummins	Hydraulic	P850569	P850569	Transmission
Case IH	600	Cummins	Hydraulic	P1050531	P1050531	Transmission
Case IH	600	Cummins	Hydraulic	P1050532	P1050532	Transmission
Case IH	600	Cummins	Hydraulic	P2050553	P2050553	Transmission
Case IH	600	Cummins	Hydraulic	P2050555	P2050555	Transmission
Case IH	600	Cummins	Hydraulic	P2050561	P2050561	Transmission
Case IH	600	Cummins	Hydraulic	P2050562	P2050562	Transmission
Case IH	600	Cummins	Hydraulic	P2050579	P2050579	Transmission
Case IH	600	Cummins	Hydraulic	P850566	P850566	Transmission
Case IH	600	Cummins	Hydraulic	P850568	P850568	Transmission
Case IH	600	Cummins	Hydraulic	P850569	P850569	Transmission
Case IH	600	Deutz	Hydraulic	P1050531	P1050531	Transmission
Case IH	600	Deutz	Hydraulic	P1050532	P1050532	Transmission
Case IH	600	Deutz	Hydraulic	P1050595	P1050595	Transmission
Case IH	600	Deutz	Hydraulic	P2050562	P2050562	Transmission
Case IH	600	Deutz	Hydraulic	P2050574	P2050574	Transmission
Case IH	600	Deutz	Hydraulic	P850566	P850566	Transmission
Case IH	600	Deutz	Hydraulic	P850568	P850568	Transmission
Case IH	600	Deutz	Hydraulic	P850569	P850569	Transmission
Case IH	600	Deutz	Hydraulic	S105531	S105531	Transmission
Case IH	600	Deutz	Hydraulic	P1050531	P1050531	Transmission
Case IH	600	Deutz	Hydraulic	P1050532	P1050532	Transmission
Case IH	600	Deutz	Hydraulic	P1050595	P1050595	Transmission
Case IH	600	Deutz	Hydraulic	P2050562	P2050562	Transmission
Case IH	600	Deutz	Hydraulic	P2050574	P2050574	Transmission
Case IH	600	Deutz	Hydraulic	P850566	P850566	Transmission
Case IH	600	Deutz	Hydraulic	P850568	P850568	Transmission
Case IH	600	Deutz	Hydraulic	P850569	P850569	Transmission
Case IH	600	Deutz	Hydraulic	S105531	S105531	Transmission

Case IH	600		Gas	Hydraulic	34457	34457	
Case IH	621	Cummins	6BT5.9	Lube	J908640	J908640	
Case IH	621	Cummins	6BT5.9	Air, Inner	A47033	A47033	
Case IH	621	Cummins	6BT5.9	Air, Outer	A47032	A47032	
Case IH	621	Cummins	6BT5.9	Cab Air	1970006C2	1970006C2	
Case IH	621	Cummins	6BT5.9	Cab Air	1970098C1	1970098C1	Recirculating
Case IH	621	Cummins	6BT5.9	Fuel	J925274	J925274	Primary
Case IH	621	Cummins	6BT5.9	Fuel	J903640	J903640	Secondary
Case IH	621	Cummins	6BT5.9	Hydraulic	N9025	N9025	
Case IH	621	Cummins	6BT5.9	Hydraulic	L104990	L104990	Tank
Case IH	621	Cummins	6BT5.9	Hydraulic	S300744	S300744	Transmission
Case IH	621	Cummins	6BT5.9	Hydraulic	S305020	S305020	Transmission
Case IH	650			Lube	J908650	J908650	
Case IH	650			Air, Inner	A47033	A47033	Inner
Case IH	650			Air, Outer	A47032	A47032	Outer
Case IH	650			Fuel	J925274	J925274	Primary
Case IH	650			Fuel	J903640	J903640	Secondary
Case IH	650			Hydraulic	N9025	N9025	
Case IH	650			Hydraulic	R55043	R55043	Reservoir
Case IH	650			Hydraulic	D37035	D37035	Suction
Case IH	650		C-350 Gas	Lube	376376R91	376376R91	
Case IH	650		Diesel	Lube	376376R91	376376R91	
Case IH	650		Diesel	Fuel	259479R92	259479R92	
Case IH	650		Gas	Lube	376376R91	376376R91	
Case IH	660			Lube	A306696	A306696	
Case IH	660			Lube	J908650	J908650	
Case IH	660			Air, Inner	3140569R2	3140569R2	
Case IH	660			Air, Inner	D37976	D37976	
Case IH	660			Air, Outer	2065510C1	2065510C1	
Case IH	660			Air, Outer	F84998	F84998	
Case IH	660			Fuel/Water Separator, Primary	J903410	J903410	1991-On
Case IH	660			Fuel	A22001	A22001	Primary
Case IH	660			Fuel	A52046	A52046	Secondary
Case IH	660			Fuel	J903640	J903640	Secondary
Case IH	660			Fuel Filter, In-Line	D209225	D209225	Tank
Case IH	660			Hydraulic	D206922	D206922	
Case IH	660			Gasket	D37976	D37976	Outer Air
Case IH	660	Case IH	6188D	Lube	J908650	J908650	
Case IH	660	Case IH	6188D	Air, Inner	3140569R2	3140569R2	
Case IH	660	Case IH	6188D	Air, Outer	2065510C1	2065510C1	
Case IH	660	Case IH	6188D	Fuel	J925274	J925274	Primary
Case IH	660	Case IH	6188D	Fuel	J903640	J903640	Secondary
Case IH	660	Case IH	6188D	Fuel In-Line	D209225	D209225	Tank
Case IH	660	Case IH	6188D	Hydraulic	D206922	D206922	Assembly Return and Charge
Case IH	660	Case IH	6188D	Gasket	D37976	D37976	

Case IH	688			Lube	J908650	J908650	
Case IH	688			Air, Outer	P1950555	P1950555	P.I.N. 40001 ON
Case IH	688			Air, Inner	P250581	P250581	P.I.N. 40001-On
Case IH	688			Air, Outer	P1950582	P1950582	To P.I.N. 40001
Case IH	688			Air, Inner	P2400506	P2400506	To P.I.N. 40001
Case IH	688			Fuel	J925274	J925274	Primary
Case IH	688			Fuel	J903640	J903640	Secondary
Case IH	688			Fuel	P50537	P50537	Tank
Case IH	688			Hydraulic	P2950520	P2950520	
Case IH	688			Hydraulic	P1950574	P1950574	Leak Return Line
Case IH	721	Cummins	6CT8.3	Lube	A77537	A77537	
Case IH	721	Cummins	6CT8.3	Air, Inner	S238647	S238647	
Case IH	721	Cummins	6CT8.3	Air, Outer	S238646	S238646	
Case IH	721	Cummins	6CT8.3	Cab Air	1970006C2	1970006C2	
Case IH	721	Cummins	6CT8.3	Cab Air	1970098C1	1970098C1	
Case IH	721	Cummins	6CT8.3	Fuel	J925274	J925274	Primary
Case IH	721	Cummins	6CT8.3	Fuel	J903640	J903640	Secondary
Case IH	721	Cummins	6CT8.3	Hydraulic	N9025	N9025	
Case IH	721	Cummins	6CT8.3	Hydraulic	S305020	S305020	Transmission
Case IH	721	Cummins	6CT8.3	Coolant	A77544	A77544	
Case IH	750			Lube	A20822	A20822	
Case IH	750			Fuel	A57228	A57228	In-Line
Case IH	750			Fuel	A22001	A22001	Primary
Case IH	750			Fuel	A7627	A7627	Secondary
Case IH	750			Hydraulic	R20605	R20605	
Case IH	750		A301	Lube	A20822	A20822	
Case IH	750		A301	Fuel	A57228	A57228	
Case IH	750		A301	Fuel	A22001	A22001	Primary
Case IH	750		A301	Fuel	A7627	A7627	Secondary
Case IH	750		A301	Hydraulic	34457	34457	To S/N-7070350
Case IH	760			Lube	J908650	J908650	
Case IH	760			Air, Inner	A603291	A603291	
Case IH	760			Air, Outer	A603290	A603290	
Case IH	760			Fuel	J925274	J925274	Primary
Case IH	760			Fuel	J903640	J903640	Secondary
Case IH	760			Hydraulic	H439069	H439069	
Case IH	760			Hydraulic	H402099	H402099	Screen
Case IH	800			Fuel	72320	72320	Primary
Case IH	800			Fuel	F27228	F27228	Secondary
Case IH	800			Hydraulic	34457	34457	Before SN# 7081201
Case IH	850			Lube	A44081	A44081	S/N 7073469-707650 0
Case IH	850			Lube	J908640	J908640	S/N 7073469-707650 0
Case IH	850			Lube	A306696	A306696	S/N

							7073469-707650 0
Case IH	850	Lube	A44081	A44081	S/N-- 10093006-On		S/N 7073469-707650 0
Case IH	850	Lube	A306696	A306696	To S/N-10093006		S/N 7073469-707650 0
Case IH	850	Air, Inner	S160746	S160746			S/N 7073469-707650 0
Case IH	850	Air, Inner	A47033	A47033			S/N 7073469-707650 0
Case IH	850	Air, Outer	S160745	S160745			S/N 7073469-707650 0
Case IH	850	Air, Outer	A47032	A47032			S/N 7073469-707650 0
Case IH	850	Air, Outer	A40866	A40866			S/N 7073469-707650 0
Case IH	850	Air, Outer	A40866	A40866			S/N 7073469-707650 0
Case IH	850	Cab Air	F44730	F44730			S/N 7073469-707650 0
Case IH	850	Cab Air	F44730	F44730			S/N 7073469-707650 0
Case IH	850	Air, Outer	D56453	D56453	Turbo		S/N 7073469-707650 0
Case IH	850	Fuel	A43344	A43344	Injection Pump		S/N 7073469-707650 0
Case IH	850	Fuel	A43344	A43344	Injection Pump		S/N 7073469-707650 0
Case IH	850	Fuel	A43344	A43344	Injection Pump		S/N 7073469-707650 0
Case IH	850	Fuel Filter	A43344	A43344	Injection Pump		S/N 7073469-707650 0
Case IH	850	Fuel	A46045	A46045	Kit		S/N 7073469-707650 0
Case IH	850	Fuel	A46045	A46045	Kit		S/N 7073469-707650 0
Case IH	850	Fuel	A46045	A46045	Primary		S/N 7073469-707650 0
Case IH	850	Fuel	J903640	J903640	Secondary		S/N 7073469-707650 0

Case IH	850			Hydraulic	A45625	A45625		S/N 7073469-707650 0
Case IH	850			Hydraulic	D35995	D35995		S/N 7073469-707650 0
Case IH	850			Hydraulic	A45625	A45625	Kit	S/N 7073469-707650 0
Case IH	850			Hydraulic	S140005	S140005	Pressure	S/N 7073469-707650 0
Case IH	850			Hydraulic	A65854	A65854	Pressure	S/N 7073469-707650 0
Case IH	850			Hydraulic	L18659	L18659	Suction	S/N 7073469-707650 0
Case IH	850			Hydraulic	D32220	D32220	Suction	S/N 7073469-707650 0
Case IH	850			Hydraulic	D55204	D55204	Tank	S/N 7073469-707650 0
Case IH	850			Hydraulic	D33557	D33557	Tank	S/N 7073469-707650 0
Case IH	850			Hydraulic	D306735	D306735	Transfer Pump	S/N 7073469-707650 0
Case IH	850			Hydraulic	D306735	D306735	Transfer Pump	S/N 7073469-707650 0
Case IH	850			Lube	A20822	A20822		TO S/N 7073469
Case IH	850			Air, Outer	A40866	A40866		TO S/N 7073469
Case IH	850			Fuel Filter, In-Line	A57228	A57228	Final	TO S/N 7073469
Case IH	850			Fuel	A22001	A22001	Primary	TO S/N 7073469
Case IH	850			Fuel	A7627	A7627	Secondary	TO S/N 7073469
Case IH	850			Hydraulic	D35995	D35995		TO S/N 7073469
Case IH	850			Hydraulic	A65854	A65854	Pressure	TO S/N 7073469
Case IH	850			Hydraulic	D32220	D32220	Suction	TO S/N 7073469
Case IH	850			Hydraulic	D33557	D33557	Tank	TO S/N 7073469
Case IH	850	Case IH	A-126	Lube	A306696	A306696		
Case IH	860	Cummins	4B3.9	Lube	J908650	J908650		
Case IH	860	Cummins	4B3.9	Air, Inner	N8403	N8403		
Case IH	860	Cummins	4B3.9	Air, Outer	D56453	D56453		
Case IH	860	Cummins	4B3.9	Fuel	J903202	J903202		
Case IH	860	Cummins	4B3.9	Fuel	J843760	J843760	Primary	
Case IH	860	Cummins	4B3.9	Hydraulic	N30232	N30232	Pump	
Case IH	860	Cummins	4B3.9	Hydraulic	2029230C1	2029230C1	Return	
Case IH	860	Cummins	4B3.9	Hydraulic	A607605	A607605	Return	
Case IH	880			Lube	A75294	A75294	S/N-10093006 ON	
Case IH	880			Lube	A306696	A306696	To S/N-10093006	

Case IH	880			Air, Outer	A40866	A40866	
Case IH	880			Fuel Filter	A43344	A43344	Injection Pump
Case IH	880			Fuel Filter	A46045	A46045	Kit
Case IH	880			Hydraulic	S62434	S62434	
Case IH	880			Hydraulic	S233969	S233969	Strainer
Case IH	880			Hydraulic	S520507	S520507	Tank
Case IH	888			Lube	J908640	J908640	
Case IH	888			Air, Inner	A47033	A47033	P.I.N. 106801 ON
Case IH	888			Air, Outer	A47032	A47032	P.I.N. 106801 ON
Case IH	888			Air, Inner	P2400506	P2400506	To P.I.N. 40401
Case IH	888			Air, Outer	P1950582	P1950582	To P.I.N. 40401
Case IH	888			Fuel	J925274	J925274	Primary
Case IH	888			Fuel	J903640	J903640	Secondary
Case IH	888			Fuel	P50537	P50537	Tank
Case IH	888			Hydraulic	P2950520	P2950520	
Case IH	888			Hydraulic	P1950574	P1950574	Leak Return Line
Case IH	921	Cummins	LTA-10-C	Lube	907101T1	907101T1	
Case IH	921	Cummins	LTA-10-C	Air, Inner	627976C1	627976C1	
Case IH	921	Cummins	LTA-10-C	Air, Outer	627975C2	627975C2	
Case IH	921	Cummins	LTA-10-C	Cab Air	1970006C2	1970006C2	
Case IH	921	Cummins	LTA-10-C	Cab Air	1970098C1	1970098C1	
Case IH	921	Cummins	LTA-10-C	Fuel	903941T1	903941T1	
Case IH	921	Cummins	LTA-10-C	Hydraulic	N9086	N9086	
Case IH	921	Cummins	LTA-10-C	Hydraulic	S302041	S302041	Suction
Case IH	921	Cummins	LTA-10-C	Hydraulic	L209303	L209303	Tank
Case IH	921	Cummins	LTA-10-C	Coolant	A77544	A77544	
Case IH	921	Cummins	LTA-10-C	Coolant	J318318	J318318	
Case IH	980			Lube	A64453	A64453	
Case IH	980			Air, Outer	L33920	L33920	
Case IH	980			Fuel	A43344	A43344	Injection Pump
Case IH	980			Fuel	A46045	A46045	Kit
Case IH	980			Hydraulic	S2333969	S2333969	
Case IH	980			Hydraulic	S62434	S62434	
Case IH	980			Hydraulic	S26293	S26293	Tank
Case IH	1000	Cummins		Hydraulic	P1050506	P1050506	Transmission
Case IH	1000	Cummins		Hydraulic	P1050507	P1050507	Transmission
Case IH	1000	Cummins		Hydraulic	P1050545	P1050545	Transmission
Case IH	1000	Cummins		Hydraulic	P1050545	P1050545	Transmission
Case IH	1000	Cummins		Hydraulic	P1050547	P1050547	Transmission
Case IH	1000	Cummins		Hydraulic	P2050553	P2050553	Transmission
Case IH	1000	Cummins		Hydraulic	P2050555	P2050555	Transmission
Case IH	1000	Cummins		Hydraulic	P2050561	P2050561	Transmission
Case IH	1000	Cummins		Hydraulic	P2050562	P2050562	Transmission
Case IH	1000	Cummins		Hydraulic	P2050579	P2050579	Transmission
Case IH	1000	Cummins		Hydraulic	P850566	P850566	Transmission

Case IH	1000	Cummins	Hydraulic	P850568	P850568	Transmission
Case IH	1000	Cummins	Hydraulic	P850569	P850569	Transmission
Case IH	1000	Deutz	Hydraulic	P1050506	P1050506	Transmission
Case IH	1000	Deutz	Hydraulic	P1050507	P1050507	Transmission
Case IH	1000	Deutz	Hydraulic	P1050545	P1050545	Transmission
Case IH	1000	Deutz	Hydraulic	P1050545	P1050545	Transmission
Case IH	1000	Deutz	Hydraulic	P1050547	P1050547	Transmission
Case IH	1000	Deutz	Hydraulic	P1050595	P1050595	Transmission
Case IH	1000	Deutz	Hydraulic	P2050562	P2050562	Transmission
Case IH	1000	Deutz	Hydraulic	P2050575	P2050575	Transmission
Case IH	1000	Deutz	Hydraulic	P850566	P850566	Transmission
Case IH	1000	Deutz	Hydraulic	P850568	P850568	Transmission
Case IH	1000	Deutz	Hydraulic	P850569	P850569	Transmission
Case IH	1000	Deutz	Hydraulic	S105531	S105531	Transmission
Case IH	1080		Lube	A75294	A75294	
Case IH	1080		Air, Inner	N6660	N6660	
Case IH	1080		Air, Outer	S231996	S231996	
Case IH	1080		Fuel	A43344	A43344	Injection Pump
Case IH	1080		Fuel	A44068	A44068	Kit
Case IH	1080		Hydraulic	S140005	S140005	
Case IH	1080		Hydraulic	S530984	S530984	Tank
Case IH	1085		Air, Inner	R36361	R36361	
Case IH	1085		Air, Outer	R29295	R29295	
Case IH	1085		Fuel	S540208	S540208	
Case IH	1085		Hydraulic	S107791	S107791	
Case IH	1085		Hydraulic	S108971	S108971	Suction Line
Case IH	1085		Hydraulic	L104990	L104990	Tank
Case IH	1085		Hydraulic	N9960	N9960	Torque Converter
Case IH	1086		Air, Inner	R36361	R36361	
Case IH	1086		Air, Outer	R29295	R29295	
Case IH	1086		Fuel	S540208	S540208	
Case IH	1086		Hydraulic	S107791	S107791	
Case IH	1086		Hydraulic	S108971	S108971	Suction Line
Case IH	1086		Hydraulic	L104990	L104990	Tank
Case IH	1086		Hydraulic	N9960	N9960	Torque Converter
Case IH	1088		Lube	J908640	J908640	
Case IH	1088		Air, Inner	A47033	A47033	
Case IH	1088		Air, Outer	A47032	A47032	
Case IH	1088		Fuel	J925274	J925274	Primary
Case IH	1088		Fuel	J903640	J903640	Secondary
Case IH	1088		Fuel	P50537	P50537	Tank
Case IH	1088		Hydraulic	P1950574	P1950574	
Case IH	1088		Hydraulic	P2950520	P2950520	
Case IH	1150		Lube	A20822	A20822	Prior To S/N-2306540

S/N  
2205978-230651  
5

Case IH	1150	Lube	A75294	A75294	S/N-- 2306550-2572691	S/N 2205978-230651 5
Case IH	1150	Air, Outer	A40866	A40866		S/N 2205978-230651 5
Case IH	1150	Fuel Filter	A46045	A46045	Kit-S/N-- 2205978-2572691	S/N 2205978-230651 5
Case IH	1150	Fuel Primary	A22001	A22001	Prior To S/N-2205977	S/N 2205978-230651 5
Case IH	1150	Fuel Secondary	A7627	A7627	Prior To S/N-2205977	S/N 2205978-230651 5
Case IH	1150	Fuel	A57228	A57228	Secondary	S/N 2205978-230651 5
Case IH	1150	Hydraulic	D35995	D35995		S/N 2205978-230651 5
Case IH	1150	Lube	A75294	A75294		S/N 2306516-257269 1
Case IH	1150	Air, Outer	A40866	A40866		S/N 2306516-257269 1
Case IH	1150	Fuel	A46045	A46045	Primary	S/N 2306516-257269 1
Case IH	1150	Hydraulic	D35995	D35995		S/N 2306516-257269 1
Case IH	1285	Lube	A44081	A44081		
Case IH	1285	Air, Inner	S238647	S238647		
Case IH	1285	Air, Outer	S238646	S238646		
Case IH	1285	Fuel	A43344	A43344	Injection Pump	
Case IH	1285	Fuel	A44068	A44068	Kit	
Case IH	1285	Hydraulic	S140005	S140005		
Case IH	1285	Hydraulic	S202018	S202018	Suction Line	
Case IH	1285	Hydraulic	S200193	S200193	Torque Converter	
Case IH	1286	Lube	D08508-89	D0850889		
Case IH	1286	Lube	A44081	A44081		
Case IH	1286	Lube	A44081	A44081	Case Engine	
Case IH	1286	Lube	A44081	A44081	Case Engine	
Case IH	1286	Lube	L32030	L32030	Detroit Diesel Engine	
Case IH	1286	Lube	L32030	L32030	Detroit Diesel Engine	
Case IH	1286	Air, Inner	X08505-61	X0850561		
Case IH	1286	Air, Inner	N6660	N6660		
Case IH	1286	Air, Inner	N6660	N6660		
Case IH	1286	Air, Inner	S238647	S238647		
Case IH	1286	Air, Outer	L0850550	L0850550		
Case IH	1286	Air, Outer	M0850551	M0850551		

Case IH	1286			Air, Outer	X0850561	X0850561	
Case IH	1286			Air, Outer	Z0850562	Z0850562	
Case IH	1286			Air, Outer	S231996	S231996	
Case IH	1286			Air, Outer	S231996	S231996	
Case IH	1286			Air, Outer	S238646	S238646	
Case IH	1286			Fuel	B10505-95	B1050595	
Case IH	1286			Fuel	G04005-64	G0400564	
Case IH	1286			Fuel	A19578	A19578	Detroit Diesel Engine
Case IH	1286			Fuel	A19578	A19578	Detroit Diesel Engine
Case IH	1286			Fuel	A43344	A43344	Injection Pump
Case IH	1286			Fuel	A43344	A43344	Injection Pump Case Engine
Case IH	1286			Fuel	A43344	A43344	Injection Pump Case Engine
Case IH	1286			Fuel	A44068	A44068	Kit
Case IH	1286			Fuel	A44068	A44068	Kit Case Engine
Case IH	1286			Fuel	A44068	A44068	Kit Case Engine
Case IH	1286			Hydraulic	N02505-74	N0250574	
Case IH	1286			Hydraulic	N0250574	N0250574	
Case IH	1286			Hydraulic	Z0400580	Z0400580	
Case IH	1286			Hydraulic	S140005	S140005	
Case IH	1286			Hydraulic	S140005	S140005	
Case IH	1286			Hydraulic	S140005	S140005	
Case IH	1286			Hydraulic	S202018	S202018	Suction
Case IH	1286			Hydraulic	S202018	S202018	Suction
Case IH	1286			Hydraulic	S202018	S202018	Suction Line
Case IH	1286			Hydraulic	S200193	S200193	Torque Converter
Case IH	1450			Lube	A75294	A75294	F/Use With 1" Adapter
Case IH	1450			Lube	A62423	A62423	F/Use With 7/8" Adapter
Case IH	1450			Air, Inner	R36361	R36361	
Case IH	1450			Air, Outer	R29295	R29295	
Case IH	1450			Fuel	A43344	A43344	Injection Pump
Case IH	1450			Fuel	A46045	A46045	Kit
Case IH	1450			Hydraulic	R55043	R55043	
Case IH	1450			Hydraulic	D83200	D83200	Pressure
Case IH	1450			Hydraulic	R30103	R30103	Suction
Case IH	1450			Hydraulic	D42995	D42995	Tank
Case IH	1450	Case IH	504BDT	Lube	A62423	A62423	
Case IH	1450	Case IH	504BDT	Lube	A75294	A75294	
Case IH	1450	Case IH	504BDT	Fuel	A58720	A58720	
Case IH	1450	Case IH	504BDT	Fuel	A58720	A58720	
Case IH	1527		DIESEL	Hydraulic	T40403	T40403	
Case IH	1530		GAS	Lube	T40475	T40475	
Case IH	1530		GAS	Air, Outer	D48198	D48198	
Case IH	1530		GAS	Fuel	A40330	A40330	
Case IH	1530		GAS	Hydraulic	D73743	D73743	6 Mt. Holes
Case IH	1530		GAS	Hydraulic	T40403	T40403	W/2 Mt. Holes

Case IH	1537		GAS	Lube	A77537	A77537	
Case IH	1537		GAS	Lube	T40475	T40475	
Case IH	1537		GAS	Air, Inner	N6660	N6660	
Case IH	1537		GAS	Air, Outer	S231996	S231996	
Case IH	1537		GAS	Air, Outer	D48198	D48198	
Case IH	1537		GAS	Fuel	A40330	A40330	
Case IH	1537		GAS	Fuel	D209225	D209225	In-Line
Case IH	1537		GAS	Fuel	J925274	J925274	Primary
Case IH	1537		GAS	Fuel	J903640	J903640	Secondary
Case IH	1537		GAS	Hydraulic	S140005	S140005	
Case IH	1537		GAS	Hydraulic	D73743	D73743	6 Mt. Holes
Case IH	1537		GAS	Hydraulic	S202018	S202018	Suction
Case IH	1537		GAS	Hydraulic	T40403	T40403	W/2 Mt. Holes
Case IH	1550	Case IH	6T590	Fuel	A77470	A77470	Primary
Case IH	1550	Cummins	6CT8.3	Lube	A77537	A77537	
Case IH	1550	Cummins	6CT8.3	Air, Inner	S238647	S238647	
Case IH	1550	Cummins	6CT8.3	Air, Outer	S238646	S238646	
Case IH	1550	Cummins	6CT8.3	Cab Air	F64318	F64318	
Case IH	1550	Cummins	6CT8.3	Fuel	J925274	J925274	Primary
Case IH	1550	Cummins	6CT8.3	Fuel	J903640	J903640	Secondary
Case IH	1550	Cummins	6CT8.3	Hydraulic	R53726	R53726	
Case IH	1550	Cummins	6CT8.3	Hydraulic	D42995	D42995	Tank
Case IH	1550	Cummins	6CT8.3	Hydraulic	N30232	N30232	Transmission
Case IH	1737		Gas	Lube	A306696	A306696	
Case IH	1737		Gas	Air, Outer	D48198	D48198	
Case IH	1737		Gas	Fuel	D53499	D53499	
Case IH	1737		Gas	Hydraulic	D73743	D73743	6 Mt. Holes
Case IH	1737		Gas	Hydraulic	T40403	T40403	W/2 Mt. Holes
Case IH	1740		Diesel	Lube	A306696	A306696	
Case IH	1740		Diesel	Air, Outer	S224636	S224636	
Case IH	1740		Diesel	Air, Outer	A42274	A42274	S/N-- 9822069-On
Case IH	1740		Diesel	Air, Outer	D48198	D48198	To S/N-9822069
Case IH	1740		Diesel	Fuel Filter Kit	A402081	A402081	S/N-- 2718940-On
Case IH	1740		Diesel	Fuel Primary	A35863	A35863	To S/N-2718940
Case IH	1740		Diesel	Fuel Secondary	A52046	A52046	To S/N-2718940
Case IH	1740		Diesel	Hydraulic	S234404	S234404	
Case IH	1740		Diesel	Hydraulic	D73743	D73743	6 Mt. Holes
Case IH	1740		Diesel	Hydraulic	S104306	S104306	Pressure
Case IH	1740		Diesel	Hydraulic	S104929	S104929	S/N-- 65521-6287228
Case IH	1740		Diesel	Hydraulic	T40403	T40403	W/2 Mt. Holes
Case IH	1816			Air, Outer	D82571	D82571	Heavy Duty
Case IH	1816			Air, Outer	D66337	D66337	Reg. Service
Case IH	1816			Fuel	D59949	D59949	
Case IH	1816			Hydraulic	D59062	D59062	
Case IH	1818		Diesel	Lube	D62845	D62845	

Case IH	1818	Diesel	Air, Outer	D82571	D82571	
Case IH	1818	Diesel	Fuel	1959599C1	1959599C1	
Case IH	1818	Diesel	Fuel	1959529C1	1959529C1	Injection Pump
Case IH	1818	Diesel	Fuel Kit Engine	1959638C1	1959638C1	Kit
Case IH	1818	Diesel	Hydraulic	D206921	D206921	
Case IH	1818	Gas	Lube	D62845	D62845	
Case IH	1818	Gas	Air, Outer	D82571	D82571	
Case IH	1818	Gas	Fuel	L79756	L79756	
Case IH	1818	Gas	Hydraulic	D206921	D206921	
Case IH	1825	Diesel	Lube	1959198C1	1959198C1	
Case IH	1825	Diesel	Air, Outer	350495A1	350495A1	
Case IH	1825	Diesel	Air, Outer	D82571	D82571	
Case IH	1825	Diesel	Fuel	1959599C2	1959599C2	
Case IH	1825	Diesel	Fuel	1959529C1	1959529C1	Injection Pump
Case IH	1825	Diesel	Fuel	1959638C1	1959638C1	Kit
Case IH	1825	Diesel	Hydraulic	D202562	D202562	
Case IH	1825	Gas	Lube	1972202C1	1972202C1	
Case IH	1825	Gas	Air, Outer	D82571	D82571	
Case IH	1825	Gas	Fuel	L79756	L79756	
Case IH	1825	Gas	Hydraulic	D202562	D202562	
Case IH	1830	Gas	Lube	D62845	D62845	
Case IH	1830	Gas	Air, Outer	D48198	D48198	
Case IH	1830	Gas	Fuel	D59949	D59949	
Case IH	1830	Gas	Hydraulic	D61950	D61950	
Case IH	1835	Diesel	Lube	A306696	A306696	
Case IH	1835	Diesel	Air, Outer	A42274	A42274	
Case IH	1835	Diesel	Fuel	A402081	A402081	Kit
Case IH	1835	Diesel	Hydraulic	D61950	D61950	For D64076 Filter
Case IH	1835	Diesel	Hydraulic	D72052	D72052	For D69097 Filter
Case IH	1835	Gas	Lube	P850589	P850589	
Case IH	1835	Gas	Lube	A306696	A306696	
Case IH	1835	Gas	Air, Outer	A42274	A42274	
Case IH	1835	Gas	Air, Inner	A43657	A43657	Heavy Duty
Case IH	1835	Gas	Air, Outer	A43656	A43656	Heavy Duty
Case IH	1835	Gas	Air, Inner	N6660	N6660	Standard Engine
Case IH	1835	Gas	Air, Outer	S231996	S231996	Standard Engine
Case IH	1835	Gas	Fuel	P400564	P400564	
Case IH	1835	Gas	Fuel	D59949	D59949	
Case IH	1835	Gas	Fuel Filter	P50537	P50537	Tank
Case IH	1835	Gas	Hydraulic	P250574	P250574	
Case IH	1835	Gas	Hydraulic	D61950	D61950	
Case IH	1835	Gas	Hydraulic	D72052	D72052	For D69097 Filter
Case IH	1835	Gas	Hydraulic	P1050527	P1050527	Return
Case IH	1838		Lube	206385A1	206385A1	
Case IH	1838		Air, Inner	203721A1	203721A1	

Case IH	1838			Air, Outer	203720A1	203720A1	
Case IH	1838			Fuel	J843760	J843760	
Case IH	1838			Hydraulic	D206922	D206922	
Case IH	1840	Cummins	4B3.9	Lube	J908650	J908650	
Case IH	1840	Cummins	4B3.9	Air, Inner	A603291	A603291	
Case IH	1840	Cummins	4B3.9	Air, Outer	A603290	A603290	
Case IH	1840	Cummins	4B3.9	Fuel	J843760	J843760	Single Application
Case IH	1840	Cummins	4B3.9	Hydraulic	D206922	D206922	
Case IH	1845			Lube	A306696	A306696	
Case IH	1845			Air, Outer	A42274	A42274	
Case IH	1845			Fuel	D53499	D53499	
Case IH	1845			Hydraulic	D61950	D61950	
Case IH	1845			Hydraulic	D72052	D72052	
Case IH	1845		Diesel	Lube	A306696	A306696	
Case IH	1845		Diesel	Air, Outer	A42274	A42274	
Case IH	1845		Diesel	Fuel	A402081	A402081	Primary
Case IH	1845		Diesel	Hydraulic	D61950	D61950	For D64076 Filter
Case IH	1845		Diesel	Hydraulic	D72052	D72052	For D69097 Filter
Case IH	6010			Lube	365129A1	365129A1	
Case IH	6010			Fuel	J931062	J931062	Spin-on
Case IH	6010			Fuel	D139225	D139225	In-line
Case IH	6010			Air	133720A1	133720A1	Outer
Case IH	6010			Air	133721A1	133721A1	Inner
Case IH	6010			Hydraulic	A165029	A165029	Charge
Case IH	6010			Hydraulic	H435725	H435725	Return
Case IH	6010			Hydraulic	H151399	H151399	Screen
Case IH	9010			Lube	J908650	J908650	
Case IH	9010			Air, Inner	400482A1	400482A1	
Case IH	9010			Air, Outer	400478A1	400478A1	
Case IH	9010			Fuel	D305357	D305357	In-Line
Case IH	9010			Fuel	J925274	J925274	Primary
Case IH	9010			Fuel	J903640	J903640	Secondary
Case IH	9010			Fuel	400306A1	400306A1	Tank
Case IH	9010			Hydraulic	404052A1	404052A1	In-Line
Case IH	9010			Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9010			Hydraulic	400794A1	400794A1	Return Line
Case IH	9010			Hydraulic	403190A1	403190A1	Tank
Case IH	9020			Lube	A306696	A306696	
Case IH	9020			Lube	J908650	J908650	
Case IH	9020			Air, Inner	400482A1	400482A1	
Case IH	9020			Air, Outer	L33920	L33920	
Case IH	9020			Air, Outer	400478A1	400478A1	
Case IH	9020			Fuel	D305357	D305357	In-Line
Case IH	9020			Fuel	A46045	A46045	Kit
Case IH	9020			Fuel	J925274	J925274	Primary

Case IH	9020	Fuel	J903640	J903640	Secondary
Case IH	9020	Fuel	400306A1	400306A1	Tank
Case IH	9020	Hydraulic	R55043	R55043	
Case IH	9020	Hydraulic	404052A1	404052A1	In-Line
Case IH	9020	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9020	Hydraulic	400794A1	400794A1	Return Line
Case IH	9020	Hydraulic	403190A1	403190A1	Tank
Case IH	9030	Lube	J908640	J908640	
Case IH	9030	Air, Inner	403240A1	403240A1	
Case IH	9030	Air, Outer	403239A1	403239A1	
Case IH	9030	Fuel	D305357	D305357	In-Line
Case IH	9030	Fuel	J925274	J925274	Primary
Case IH	9030	Fuel	J903640	J903640	Secondary
Case IH	9030	Fuel	400306A1	400306A1	Tank
Case IH	9030	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9030	Hydraulic	400794A1	400794A1	Return Line
Case IH	9030	Hydraulic	403468A1	403468A1	Tank
Case IH	9040	Lube	J919562	J919562	
Case IH	9040	Air, Inner	402097A1	402097A1	
Case IH	9040	Air, Outer	400783A1	400783A1	
Case IH	9040	Fuel	D305357	D305357	In-Line
Case IH	9040	Fuel	J925274	J925274	Primary
Case IH	9040	Fuel	J903640	J903640	Secondary
Case IH	9040	Fuel	400306A1	400306A1	Tank
Case IH	9040	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9040	Hydraulic	400794A1	400794A1	Return Line
Case IH	9040	Hydraulic	403220A1	403220A1	Tank
Case IH	9040	Coolant	A77544	A77544	
Case IH	9050	Lube	402097A1	402097A1	
Case IH	9050	Air, Inner	402097A1	402097A1	
Case IH	9050	Air, Outer	400783A1	400783A1	
Case IH	9050	Fuel	ME069671	ME069671	FFWS
Case IH	9050	Fuel	400306A1	400306A1	Tank
Case IH	9050	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9050	Hydraulic	400794A1	400794A1	Return Line
Case IH	9050	Hydraulic	403344A1	403344A1	Tank
Case IH	9050	Coolant	A77544	A77544	
Case IH	9060	Lube	402097A1	402097A1	
Case IH	9060	Air, Inner	402097A1	402097A1	
Case IH	9060	Air, Outer	400783A1	400783A1	
Case IH	9060	Fuel	408668A1	408668A1	FFWS
Case IH	9060	Fuel	400306A1	400306A1	Tank
Case IH	9060	Hydraulic	403026A1	403026A1	Pilot Line
Case IH	9060	Hydraulic	400794A1	400794A1	Return Line
Case IH	9060	Hydraulic	403030A1	403030A1	Tank

Case IH	9060	Coolant	A77544	A77544		
Case IH	1000B	Lube	35034	35034		S/N 7010001-710120 0
Case IH	1000B	Fuel	72320	72320	Primary	S/N 7010001-710120 0
Case IH	1000B	Fuel	A57228	A57228	Secondary	S/N 7010001-710120 0
Case IH	1000C	Air, Outer	D32625	D32625		
Case IH	1000C	Fuel	A57228	A57228		
Case IH	1000C	Fuel	G45006	G45006	Secondary	
Case IH	1000C	Hydraulic	34457	34457	Transmission	
Case IH	1000D	Lube	35034	35034		S/N 7103001 ON
Case IH	1000D	Fuel	72320	72320	Primary	S/N 7103001 ON
Case IH	1000D	Fuel	A57228	A57228	Secondary	S/N 7103001 ON
Case IH	1080B	Lube	A75294	A75294		
Case IH	1080B	Air, Inner	N6660	N6660		
Case IH	1080B	Air, Outer	S231996	S231996		
Case IH	1080B	Fuel	A43344	A43344	Injection Pump	
Case IH	1080B	Fuel	A44068	A44068	Kit	
Case IH	1080B	Hydraulic	S140005	S140005		
Case IH	1080B	Hydraulic	S530984	S530984	Tank	
Case IH	1085B	Lube	J908640	J908640		
Case IH	1085B	Air, Inner	R36361	R36361		
Case IH	1085B	Air, Outer	R29295	R29295		
Case IH	1085B	Fuel	J925274	J925274	Primary	
Case IH	1085B	Fuel	J903640	J903640	Secondary	
Case IH	1085B	Hydraulic	S107791	S107791		
Case IH	1085B	Hydraulic	S108971	S108971	Suction Line	
Case IH	1085B	Hydraulic	L104990	L104990	Tank	
Case IH	1085B	Hydraulic	N9960	N9960	Torque Converter	
Case IH	1085C	Lube	J908640	J908640		
Case IH	1085C	Air, Inner	R36361	R36361		
Case IH	1085C	Air, Outer	R29295	R29295		
Case IH	1085C	Fuel	D209225	D209225	In-Line Tank	
Case IH	1085C	Fuel	J925274	J925274	Primary	
Case IH	1085C	Fuel	J903640	J903640	Secondary	
Case IH	1085C	Hydraulic	N9086	N9086	P505659	
Case IH	1085C	Hydraulic	S160479	S160479	Tank	
Case IH	1085C	Hydraulic	N9025	N9025	Transmission	
Case IH	1086B	Lube	J908640	J908640		
Case IH	1086B	Air, Inner	R36361	R36361		
Case IH	1086B	Air, Outer	R29295	R29295		
Case IH	1086B	Fuel	J925274	J925274	Primary	
Case IH	1086B	Fuel	J903640	J903640	Secondary	
Case IH	1086B	Hydraulic	S107791	S107791		

Case IH	1086B		Hydraulic	S108971	S108971	Suction Line
Case IH	1086B		Hydraulic	L104990	L104990	Tank
Case IH	1086B		Hydraulic	N9960	N9960	Torque Converter
Case IH	1150B		Lube	A75294	A75294	
Case IH	1150B		Air, Inner	R36361	R36361	
Case IH	1150B		Air, Outer	L33920	L33920	
Case IH	1150B		Air, Outer	R29295	R29295	
Case IH	1150B		Fuel	A43344	A43344	Injection Pump
Case IH	1150B		Fuel Filter	A46045	A46045	Kit
Case IH	1150B		Hydraulic	R55043	R55043	
Case IH	1150B		Hydraulic	G102201	G102201	Pressure
Case IH	1150B		Hydraulic	R30103	R30103	Suction
Case IH	1150B		Hydraulic	D42995	D42995	Tank
Case IH	1150B	451BD	Lube	A58672	A58672	
Case IH	1150B	451BD	Air, Outer	L33920	L33920	
Case IH	1150B	451BD	Fuel	A58720	A58720	Primary
Case IH	1150B	451BD	Fuel	A58720	A58720	Secondary
Case IH	1150C		Lube	A75294	A75294	Req. 2 F/Alt. Compensating Eng
Case IH	1150C		Air, Inner	R36361	R36361	
Case IH	1150C		Air, Outer	R29295	R29295	
Case IH	1150C		Cab Air	F64318	F64318	
Case IH	1150C		Fuel Filter	A43344	A43344	Injection Pump
Case IH	1150C		Fuel Filter	A46045	A46045	Kit
Case IH	1150C		Hydraulic	R55043	R55043	
Case IH	1150C		Hydraulic	G102201	G102201	Pressure
Case IH	1150C		Hydraulic	R30103	R30103	Suction
Case IH	1150C		Hydraulic	D42995	D42995	Tank
Case IH	1150D		Lube	A44081	A44081	
Case IH	1150D		Air, Inner	R36361	R36361	
Case IH	1150D		Air, Outer	R29295	R29295	
Case IH	1150D		Cab Air	F64318	F64318	
Case IH	1150D		Fuel	A43344	A43344	Injection Pump
Case IH	1150D		Fuel Filter	A46045	A46045	Kit
Case IH	1150D		Hydraulic	R55043	R55043	
Case IH	1150D		Hydraulic	N30080	N30080	Pressure
Case IH	1150D		Hydraulic	R30103	R30103	Suction
Case IH	1150D		Hydraulic	D42995	D42995	Tank
Case IH	1150E	6T-590	Lube	J908640	J908640	
Case IH	1150E	6T-590	Air, Inner	R36361	R36361	
Case IH	1150E	6T-590	Air, Outer	R29295	R29295	
Case IH	1150E	6T-590	Cab Air	F64318	F64318	
Case IH	1150E	6T-590	Fuel	J925274	J925274	Primary
Case IH	1150E	6T-590	Fuel	J903640	J903640	Secondary
Case IH	1150E	6T-590	Hydraulic	R55043	R55043	
Case IH	1150E	6T-590	Hydraulic	S233969	S233969	Suction

Case IH	1150E		6T-590	Hydraulic	A18789	A18789	Tank
Case IH	1150E		6T-590	Hydraulic	N9086	N9086	Transmission
Case IH	1150E		6T-590	Coolant	A77543	A77543	
Case IH	1150E		6T-590	Coolant	A77544	A77544	
Case IH	1150E		6T-830	Lube	A77537	A77537	
Case IH	1150E		6T-830	Air, Inner	R36361	R36361	
Case IH	1150E		6T-830	Air, Outer	R29295	R29295	
Case IH	1150E		6T-830	Cab Air	F64318	F64318	
Case IH	1150E		6T-830	Fuel	J925274	J925274	Primary
Case IH	1150E		6T-830	Fuel	J903640	J903640	Secondary
Case IH	1150E		6T-830	Hydraulic	R55043	R55043	
Case IH	1150E		6T-830	Hydraulic	S233969	S233969	Suction
Case IH	1150E		6T-830	Hydraulic	A18789	A18789	Tank
Case IH	1150E		6T-830	Hydraulic	N9086	N9086	Transmission
Case IH	1150E		6T-830	Coolant	A77543	A77543	
Case IH	1150E		6T-830	Coolant	A77544	A77544	
Case IH	1150G			Lube	J908640	J908640	
Case IH	1150G			Air, Inner	R36361	R36361	
Case IH	1150G			Air, Outer	R29295	R29295	
Case IH	1150G			Cab Air	F64318	F64318	
Case IH	1150G			Fuel	J925274	J925274	Primary
Case IH	1150G			Fuel	J903640	J903640	Secondary
Case IH	1150G			Fuel	R57888	R57888	Tank
Case IH	1150G			Hydraulic	R55043	R55043	Reservoir
Case IH	1150G			Hydraulic	S233969	S233969	Suction
Case IH	1150G			Hydraulic	N9086	N9086	Transmission
Case IH	1150H			Lube	J937345	J937345	Standard
Case IH	1150H			Lube	J934430	J934430	Premium
Case IH	1150H			Fuel	J930942	J930942	Primary
Case IH	1150H			Fuel	J903640	J903640	Secondary
Case IH	1150H			Air	187471A1	187471A1	Outer
Case IH	1150H			Air	187472A1	187472A1	Inner
Case IH	1150H			Air	F64318	F64318	Cab
Case IH	1150H			Hydraulic	N9086	N9086	
Case IH	1150H			Transmission	S233969	S233969	
Case IH	1155D	Case IH	A504BD	Lube	A44081	A44081	
Case IH	1155D	Case IH	A504BD	Air, Inner	R36361	R36361	
Case IH	1155D	Case IH	A504BD	Air, Outer	R29295	R29295	
Case IH	1155D	Case IH	A504BD	Cab Air	F64318	F64318	
Case IH	1155D	Case IH	A504BD	Fuel	A43344	A43344	Injection Pump
Case IH	1155D	Case IH	A504BD	Fuel	A46045	A46045	Kit
Case IH	1155D	Case IH	A504BD	Hydraulic	R55043	R55043	
Case IH	1155D	Case IH	A504BD	Hydraulic	N30080	N30080	Pressure
Case IH	1155D	Case IH	A504BD	Hydraulic	R30103	R30103	Suction
Case IH	1155D	Case IH	A504BD	Hydraulic	D42995	D42995	Tank

Case IH	1155E	6T-590	Lube	J908640	J908640	
Case IH	1155E	6T-590	Air, Inner	R36361	R36361	
Case IH	1155E	6T-590	Air, Outer	R29295	R29295	
Case IH	1155E	6T-590	Cab Air	F64318	F64318	
Case IH	1155E	6T-590	Fuel/Water Separator, Primary	A77470	A77470	1991-0N
Case IH	1155E	6T-590	Hydraulic	N9086	N9086	Transmission
Case IH	1155E	6T-590	Coolant	A77543	A77543	
Case IH	1155E	6T-590	Coolant	A77544	A77544	
Case IH	1155E	6T-830	Lube	A77537	A77537	
Case IH	1155E	6T-830	Lube	J908640	J908640	W/6T-590
Case IH	1155E	6T-830	Air, Inner	R36361	R36361	
Case IH	1155E	6T-830	Air, Outer	R29295	R29295	
Case IH	1155E	6T-830	Cab Air	F64318	F64318	
Case IH	1155E	6T-830	Fuel	J925274	J925274	Primary
Case IH	1155E	6T-830	Fuel	J903640	J903640	Secondary
Case IH	1155E	6T-830	Hydraulic	R55043	R55043	
Case IH	1155E	6T-830	Hydraulic	S233969	S233969	Suction
Case IH	1155E	6T-830	Hydraulic	A18789	A18789	Tank
Case IH	1155E	6T-830	Hydraulic	N9086	N9086	Transmission
Case IH	1155E	6T-830	Coolant	A77543	A77543	
Case IH	1155E	6T-830	Coolant	A77544	A77544	
Case IH	115P		Lube	P850589	P850589	
Case IH	115P		Air, Inner	A43657	A43657	
Case IH	115P		Air, Inner	P850561	P850561	
Case IH	115P		Air, Outer	A43656	A43656	
Case IH	115P		Air, Outer	S231996	S231996	
Case IH	115P		Fuel	P400564	P400564	
Case IH	115P		Fuel Filter	P50537	P50537	Tank
Case IH	115P		Hydraulic	P250574	P250574	
Case IH	115P		Hydraulic	P1050527	P1050527	Return
Case IH	1280B		Lube	A75294	A75294	
Case IH	1280B		Air, Inner	N6660	N6660	Case Engine
Case IH	1280B		Air, Outer	S231996	S231996	Case Engine
Case IH	1280B		Air, Inner	L35496	L35496	Detroit Diesel Engine
Case IH	1280B		Air, Outer	L35495	L35495	Detroit Diesel Engine
Case IH	1280B		Fuel	A43344	A43344	Injection Pump
Case IH	1280B		Fuel	A44068	A44068	Kit
Case IH	1280B		Hydraulic	S400428	S400428	
Case IH	1280B		Hydraulic	S105892	S105892	Suction Line
Case IH	1280B		Hydraulic	S530984	S530984	Tank
Case IH	1450B		Lube	A44081	A44081	-2
Case IH	1450B		Air, Inner	N6660	N6660	Dust Cap
Case IH	1450B		Air, Outer	S231996	S231996	Dust Cap
Case IH	1450B		Air, Inner	N6655	N6655	Strata
Case IH	1450B		Air, Outer	N6656	N6656	Strata

Case IH	1450B		Fuel	A43344	A43344	Injection Pump	
Case IH	1450B		Fuel	A44068	A44068	Kit	
Case IH	1450B		Hydraulic	R55043	R55043		
Case IH	1450B		Hydraulic	N30080	N30080	Pressure	
Case IH	1450B		Hydraulic	S233969	S233969	Suction	
Case IH	1450B		Hydraulic	D42995	D42995	Tank	
Case IH	1455B		Lube	A44081	A44081		
Case IH	1455B		Air, Inner	N6655	N6655		
Case IH	1455B		Air, Inner	N6660	N6660	Dust Cap	
Case IH	1455B		Air, Outer	S231996	S231996	Dust Cap	
Case IH	1455B		Air, Inner	N6655	N6655	Strata	
Case IH	1455B		Fuel	A43344	A43344	Injection Pump	
Case IH	1455B		Fuel	A44068	A44068	Kit	
Case IH	1455B		Hydraulic	R55043	R55043		
Case IH	1455B		Hydraulic	N30080	N30080	Pressure	
Case IH	1455B		Hydraulic	S233969	S233969	Suction	
Case IH	1455B		Hydraulic	D42995	D42995	Tank	
Case IH	150M		Lube	T40475	T40475		
Case IH	150M		Air, Outer	D48198	D48198		
Case IH	150M		Hydraulic	D73743	D73743	S/N-- 2025 ON	
Case IH	150M		Hydraulic	T40403	T40403	To S/N-2025	
Case IH	1530B		GAS	Lube	T40475	T40475	
Case IH	1530B		GAS	Air, Outer	D48198	D48198	
Case IH	1530B		GAS	Fuel	A40330	A40330	
Case IH	1530B		GAS	Hydraulic	D73743	D73743	6 Mt. Holes
Case IH	1530B		GAS	Hydraulic	T40403	T40403	W/2 Mt. Holes
Case IH	16+4	Kohler	Hydraulic	H334540	H334540	Pump	
Case IH	16+4	Kohler	Hydraulic	H228197	H228197	Suction	
Case IH	16+4	Kohler	Air, Outer	D82571	D82571		
Case IH	160CK		Lube	P850589	P850589		
Case IH	160CK		Air, Inner	A43657	A43657		
Case IH	160CK		Air, Outer	A43656	A43656		
Case IH	160CK		Cab Air	S105531	S105531	Heater	
Case IH	160CK		Air, Outer	S231996	S231996	Outer	
Case IH	160CK		Air, Inner	N6660	N6660	Standard Engine Inner	
Case IH	160CK		Fuel	P400564	P400564		
Case IH	160CK		Fuel Filter	P850566	P850566	Tank	
Case IH	160CK		Hydraulic	P400580	P400580		
Case IH	160CK		Hydraulic	P250574	P250574		
Case IH	160CK		Hydraulic	Z0400580	Z0400580		
Case IH	170B		Lube	P850589	P850589		
Case IH	170B		Air, Inner	A43657	A43657		
Case IH	170B		Air, Inner	N6660	N6660		
Case IH	170B		Air, Inner	P850561	P850561		
Case IH	170B		Air, Outer	A43656	A43656		

Case IH	170B		Air, Outer	S231996	S231996	
Case IH	170B		Fuel	P400564	P400564	
Case IH	170B		Fuel Filter	P50537	P50537	Tank
Case IH	170B		Hydraulic	P400580	P400580	
Case IH	170C		Air, Inner	A43657	A43657	
Case IH	170C		Air, Outer	A43656	A43656	
Case IH	170C		Fuel Filter	P50537	P50537	Tank
Case IH	170C		Hydraulic	P400580	P400580	
Case IH	1737S	Gas	Lube	A306696	A306696	
Case IH	1737S	Gas	Air, Outer	D48198	D48198	
Case IH	1737S	Gas	Fuel	D53499	D53499	
Case IH	1737S	Gas	Hydraulic	D73743	D73743	6 Mt. Holes
Case IH	1737S	Gas	Hydraulic	T40403	T40403	W/2 Mt. Holes
Case IH	1816B	Gas	Air, Outer	D82571	D82571	S/N-- 9822069-On
Case IH	1816B	Gas	Air, Outer	D66337	D66337	To S/N-9822069 Reg. Service
Case IH	1816B	Gas	Fuel	D59949	D59949	
Case IH	1816B	Gas	Hydraulic	D59062	D59062	
Case IH	1816C	Gas	Lube	D62845	D62845	
Case IH	1816C	Gas	Air, Outer	D82571	D82571	
Case IH	1816C	Gas	Fuel	L79756	L79756	
Case IH	1816C	Gas	Fuel Filter	D59949	D59949	74 Micron, 1.38"
Case IH	1816C	Gas	Hydraulic	D59062	D59062	
Case IH	1835B	Diesel	Lube	A306696	A306696	
Case IH	1835B	Diesel	Air, Outer	A42274	A42274	
Case IH	1835B	Diesel	Fuel	A402081	A402081	Kit
Case IH	1835B	Diesel	Hydraulic	D206922	D206922	
Case IH	1835B	Gas	Lube	A306696	A306696	
Case IH	1835B	Gas	Air, Outer	A42274	A42274	
Case IH	1835B	Gas	Fuel	D53499	D53499	
Case IH	1835B	Gas	Hydraulic	D206922	D206922	
Case IH	1835C	Diesel	Lube	1959757C1	1959757C1	
Case IH	1835C	Diesel	Air, Inner	D82775	D82775	
Case IH	1835C	Diesel	Air, Outer	S236468	S236468	
Case IH	1835C	Diesel	Fuel	1959802C1	1959802C1	
Case IH	1835C	Diesel	Hydraulic	D206922	D206922	
Case IH	1835C	Gas	Lube	1959757C1	1959757C1	
Case IH	1835C	Gas	Air, Inner	D82775	D82775	
Case IH	1835C	Gas	Air, Outer	S236468	S236468	
Case IH	1835C	Gas	Fuel	6002032C91	6002032C91	
Case IH	1835C	Gas	Hydraulic	D206922	D206922	
Case IH	1845B	Diesel	Lube	A306696	A306696	
Case IH	1845B	Diesel	Air, Outer	A42274	A42274	
Case IH	1845B	Diesel	Fuel	A402081	A402081	Kit
Case IH	1845B	Diesel	Hydraulic	D206922	D206922	
Case IH	1845B	Gas	Lube	A75294	A75294	

Case IH	1845B		Gas	Lube	A306696	A306696	
Case IH	1845B		Gas	Air, Outer	A42274	A42274	
Case IH	1845B		Gas	Air, Inner	N6660	N6660	Case Engine
Case IH	1845B		Gas	Air, Outer	S231996	S231996	Case Engine
Case IH	1845B		Gas	Air, Inner	L35496	L35496	Detroit Diesel Engine
Case IH	1845B		Gas	Air, Outer	L35495	L35495	Detroit Diesel Engine
Case IH	1845B		Gas	Fuel	D53499	D53499	
Case IH	1845B		Gas	Fuel	A43344	A43344	Injection Pump
Case IH	1845B		Gas	Fuel	A44068	A44068	Kit
Case IH	1845B		Gas	Hydraulic	S400428	S400428	
Case IH	1845B		Gas	Hydraulic	D206922	D206922	
Case IH	1845B		Gas	Hydraulic	S105892	S105892	Suction Line
Case IH	1845B		Gas	Hydraulic	S530984	S530984	Tank
Case IH	1845C	Cummins	4B3.9	Lube	J908650	J908650	
Case IH	1845C	Cummins	4B3.9	Air, Inner	A603291	A603291	
Case IH	1845C	Cummins	4B3.9	Air, Outer	A603290	A603290	
Case IH	1845C	Cummins	4B3.9	Fuel	J925274	J925274	Primary
Case IH	1845C	Cummins	4B3.9	Fuel	J903640	J903640	Secondary
Case IH	1845C	Cummins	4B3.9	Fuel Single	J843760	J843760	Single Application
Case IH	1845C	Cummins	4B3.9	Hydraulic	D206922	D206922	
Case IH	1845S		Gas	Lube	A306696	A306696	
Case IH	1845S		Gas	Air, Outer	A42274	A42274	
Case IH	1845S		Gas	Fuel	D53499	D53499	
Case IH	1845S		Gas	Hydraulic	D61950	D61950	
Case IH	1845S		Gas	Hydraulic	D72052	D72052	
Case IH	200B	Case IH	Gas	Lube	A36206	A36206	
Case IH	200B	Case IH	Gas	Hydraulic	G20203	G20203	
Case IH	200TX			Fuel	TX400031B	TX400031B	In-line
Case IH	200TX			Air	TX400031A	TX400031A	
Case IH	200TX			Hydraulic	TX405010	TX405010	
Case IH	200TX			Hydraulic	TX405250	TX405250	Tank
Case IH	220B	Detroit Diesel	6V-53	Lube	P2050575	P2050575	
Case IH	220B	Detroit Diesel	6V-53	Air, Inner	P850569	P850569	
Case IH	220B	Detroit Diesel	6V-53	Air, Outer	P850568	P850568	
Case IH	220B	Detroit Diesel	6V-53	Fuel	P1050595	P1050595	
Case IH	220B	Detroit Diesel	6V-53	Fuel	P50537	P50537	Tank
Case IH	220B	Detroit Diesel	6V-53	Hydraulic	P250574	P250574	Drain
Case IH	220B	Detroit Diesel	6V-53	Hydraulic	P1050547	P1050547	Main
Case IH	220C			Lube	P2050575	P2050575	
Case IH	220C			Air, Inner	P850569	P850569	
Case IH	220C			Cab Air	S105531	S105531	Heater
Case IH	220C			Air, Outer	P850568	P850568	Tank
Case IH	220C			Fuel	P400564	P400564	
Case IH	220C			Fuel Filter	P850566	P850566	Tank
Case IH	220C			Hydraulic	P1050574	P1050574	

Case IH	220C		Hydraulic	P250574	P250574	
Case IH	25+4	Kohler	Hydraulic	H334540	H334540	Pump
Case IH	25+4	Kohler	Hydraulic	H402099	H402099	Screen
Case IH	30 Fleethoe	Wisconsin	Air, Outer	D48198	D48198	
Case IH	30 Fleethoe	Wisconsin	Hydraulic	H340047	H340047	
Case IH	30 Fleethoe	Wisconsin	Hydraulic	H402099	H402099	Screen
Case IH	30+4	Deutz	Air, Inner	A603291	A603291	S/N-- 2032821 & After
Case IH	30+4	Deutz	Air, Outer	A603290	A603290	S/N-- 2032821 & After
Case IH	30+4	Deutz	Air, Outer	D48198	D48198	Wisc. Engine
Case IH	30+4	Deutz	Hydraulic	H340054	H340054	
Case IH	30+4	Deutz	Hydraulic	H340047	H340047	Propulsion Pump
Case IH	30+4	Deutz	Hydraulic	H402099	H402099	Screen
Case IH	30+4SP	Deutz	Hydraulic	A603290	A603290	Transmission
Case IH	30+4SP	Deutz	Hydraulic	A603291	A603291	Transmission
Case IH	30+4SP	Deutz	Hydraulic	H402099	H402099	Transmission
Case IH	30+4SP	Deutz	Hydraulic	H340047	H340047	Transmission
Case IH	30+4SP	Deutz	Hydraulic	H340054	H340054	Transmission
Case IH	300 Tree Skidder		Fuel	A19578	A19578	Final
Case IH	300B		Lube	A36206	A36206	
Case IH	300B		Hydraulic	G20203	G20203	
Case IH	300B	Diesel	Lube	G45008	G45008	
Case IH	300B	Diesel	Fuel	A57228	A57228	
Case IH	300B	Diesel	Hydraulic	G20203	G20203	
Case IH	300C Tree Skidder		Lube	A306696	A306696	
Case IH	300C Tree Skidder		Air, Outer	L33920	L33920	
Case IH	300C Tree Skidder		Fuel	A46045	A46045	Kit
Case IH	30ECYC		Air, Outer	S76237	S76237	GMC 4-53, Perkins 6-354 Engine
Case IH	30ECYC		Air, Outer	360702R91	360702R91	IHC UC263 Gas, UD282 Diesel
Case IH	30ECYC		Air, Outer	A42274	A42274	IHC UC263 Gas, UD282 Diesel
Case IH	30ECYC		Hydraulic	S62434	S62434	Pressure
Case IH	30ECYC		Hydraulic	S233969	S233969	Suction
Case IH	30YM-30YC	GM	Air, Outer	360702R91	360702R91	IHC Engine
Case IH	30YM-30YC	GM	Hydraulic	S62434	S62434	
Case IH	30YM-30YC	Navistar	Air, Outer	360702R91	360702R91	
Case IH	30YM-30YC	Navistar	Hydraulic	S62434	S62434	
Case IH	310C		Lube	A36206	A36206	
Case IH	310D		Lube	A306696	A306696	
Case IH	310D		Fuel	A35863	A35863	Primary
Case IH	310D		Fuel	A52046	A52046	Secondary
Case IH	310E		Lube	A306696	A306696	
Case IH	310E		Fuel	A35863	A35863	Primary
Case IH	310E		Fuel	A52046	A52046	Secondary
Case IH	310F		Lube	A306696	A306696	

Case IH	310F		Fuel	A35863	A35863	Primary	
Case IH	310F		Fuel	A52046	A52046	Secondary	
Case IH	310G		Lube	A306696	A306696		
Case IH	310G		Air, Outer	D48198	D48198		
Case IH	310G		Fuel	A35863	A35863	Primary	
Case IH	310G		Fuel	A52046	A52046	Secondary	
Case IH	310G		Hydraulic	D32220	D32220		
Case IH	320B	Diesel	Lube	G45008	G45008		
Case IH	320B	Diesel	Fuel	A57228	A57228		
Case IH	320B	Diesel	Hydraulic	G20203	G20203		
Case IH	320B	Gas	Lube	A36206	A36206		
Case IH	320B	Gas	Hydraulic	G20203	G20203		
Case IH	350B		Lube	A306696	A306696		
Case IH	350B		Air, Inner	D82775	D82775		
Case IH	350B		Air, Outer	S236468	S236468		
Case IH	350B		Fuel	A402081	A402081	Kit	
Case IH	350B		Hydraulic	D75831	D75831		
Case IH	350B		Hydraulic	N9025	N9025		
Case IH	35D	Case IH	Hydraulic	A19579	A19579	Transmission	S/N 6266131-ON
Case IH	35D	Case IH	Hydraulic	D56453	D56453	Transmission	S/N 6266131-ON
Case IH	35D	Case IH	Hydraulic	L32030	L32030	Transmission	S/N 6266131-ON
Case IH	35D	Case IH	Hydraulic	R29295	R29295	Transmission	S/N 6266131-ON
Case IH	35D	Case IH	Hydraulic	S107791	S107791	Transmission	S/N 6266131-ON
Case IH	35D	Case IH	Hydraulic	S108971	S108971	Transmission	S/N 6266131-ON
Case IH	35D	Case IH	Hydraulic	S400427	S400427	Transmission	S/N 6266131-ON
Case IH	35D	Case IH	Hydraulic	S233969	S233969	Transmission	S/N 6266131-ON
Case IH	35ECYC Series A		Air, Outer	360702R91	360702R91	GMC 3-53,PERK. 6-354 ENG 5-1/2	
Case IH	35ECYC Series A		Air, Outer	S76237	S76237	GMC 4-53, Perkins 6-354 Engine	
Case IH	35ECYC Series A		Air, Outer	A42274	A42274	IHC UC263 Gas, UD282 Diesel	
Case IH	35ECYC Series A		Hydraulic	S62434	S62434	Pressure	
Case IH	35ECYC Series A		Hydraulic	S233969	S233969	Suction	
Case IH	35ECYC Series B		Air, Outer	A40866	A40866	Case Engine	S/N 300-ON
Case IH	35ECYC Series B		Air, Outer	L33920	L33920	Detroit Diesel Engine	S/N 300-ON
Case IH	35ECYC Series B		Hydraulic	S62434	S62434	Pressure	S/N 300-ON
Case IH	35ECYC Series B		Hydraulic	S233969	S233969	Suction	S/N 300-ON
Case IH	35ECYC Series B		Hydraulic	S26293	S26293	Tank	S/N 300-ON
Case IH	380B		Lube	3206046R93	3206046R93		
Case IH	380B		Air, Inner	3140569R2	3140569R2		
Case IH	380B		Air, Outer	2065510C1	2065510C1		

Case IH	380B		Fuel	1967094C1	1967094C1	
Case IH	380B		Hydraulic	93420C1	93420C1	
Case IH	380CK		Lube	K200037	K200037	
Case IH	380CK		Air, Outer	K952331	K952331	Early Production
Case IH	380CK		Air, Outer	D73008	D73008	Late Production
Case IH	380CK		Fuel	3044506R93	3044506R93	
Case IH	380CK		Hydraulic	D75831	D75831	
Case IH	380CK		Hydraulic	K920522	K920522	
Case IH	380CK		Hydraulic	A42242	A42242	Steering
Case IH	380GP/LL		Lube	K200037	K200037	
Case IH	380GP/LL		Air, Outer	K952331	K952331	Early Production
Case IH	380GP/LL		Air, Outer	D73008	D73008	Late Production
Case IH	380GP/LL		Fuel	3044506R93	3044506R93	
Case IH	380GP/LL		Hydraulic	D75831	D75831	
Case IH	380GP/LL		Hydraulic	K920522	K920522	
Case IH	380GP/LL		Hydraulic	A42242	A42242	Steering
Case IH	40+4	Deutz	Air, Inner	A603291	A603291	S/N-- 2032821 & After
Case IH	40+4	Deutz	Air, Outer	A603290	A603290	S/N-- 2032821 & After
Case IH	40+4	Deutz	Hydraulic	H340054	H340054	
Case IH	40+4	Deutz	Hydraulic	H340047	H340047	Pump
Case IH	40+4	Deutz	Hydraulic	H402099	H402099	Screen
Case IH	40+4	Wisconsin	Air, Outer	D48198	D48198	
Case IH	40+4	Wisconsin	Hydraulic	H340054	H340054	
Case IH	40+4	Wisconsin	Hydraulic	H340047	H340047	Pump
Case IH	40+4	Wisconsin	Hydraulic	H402099	H402099	Screen
Case IH	400 Tree Skidder		Lube	L32030	L32030	
Case IH	400 Tree Skidder		Fuel	A19578	A19578	Final
Case IH	400B	Diesel	Lube	G45008	G45008	
Case IH	400B	Diesel	Fuel	A57228	A57228	
Case IH	400B	Diesel	Hydraulic	G20203	G20203	
Case IH	400C Tree Skidder		Lube	A306696	A306696	
Case IH	400C Tree Skidder		Air, Outer	L33920	L33920	
Case IH	400C Tree Skidder		Fuel	A46045	A46045	Kit
Case IH	400TX		Fuel	TX400031B	TX400031B	In-line
Case IH	400TX		Air	TX400031A	TX400031A	
Case IH	400TX		Hydraulic	TX405010	TX405010	
Case IH	400TX		Hydraulic	TX405250	TX405250	Tank
Case IH	40A		Air, Outer	S76237	S76237	6-1/50" Dia. S/N 100-2199
Case IH	40A		Hydraulic	S62434	S62434	Pressure S/N 100-2199
Case IH	40A		Hydraulic	S233969	S233969	Suction S/N 100-2199
Case IH	40A		Hydraulic	S26293	S26293	Tank S/N 100-2199
Case IH	40B	CASE IH	Lube	A64453	A64453	Case Engine

Case IH	40B	CASE IH	Lube	L32030	L32030	Detroit Diesel Engine	
Case IH	40B	CASE IH	Air, Outer	L33920	L33920		
Case IH	40B	CASE IH	Air, Outer	S222020	S222020	Detroit Diesel Engine	
Case IH	40B	CASE IH	Fuel Filter	A19578	A19578	Detroit Engine - Primary	
Case IH	40B	CASE IH	Fuel Filter	A43344	A43344	Injection Pump	
Case IH	40B	CASE IH	Fuel	A46045	A46045	Kit	
Case IH	40B	CASE IH	Hydraulic	S62434	S62434	Pressure	
Case IH	40B	CASE IH	Hydraulic	S233969	S233969	Suction	
Case IH	40B	CASE IH	Hydraulic	S26293	S26293	Tank	
Case IH	40B	Detroit Diesel	Lube	L32030	L32030		S/N 220-6292775
Case IH	40B	Detroit Diesel	Air, Outer	L33920	L33920		S/N 220-6292775
Case IH	40B	Detroit Diesel	Hydraulic	S62434	S62434	Pressure	S/N 220-6292775
Case IH	40D		Lube	A75294	A75294		S/N 6270716-ON
Case IH	40D		Air, Outer	S231996	S231996		S/N 6270716-ON
Case IH	40D		Fuel Filter	A19579	A19579	Detroit Diesel Engine	S/N 6270716-ON
Case IH	40D		Fuel	A43344	A43344	Injection Pump	S/N 6270716-ON
Case IH	40D		Fuel Filter	A46045	A46045	Kit	S/N 6270716-ON
Case IH	40D		Hydraulic Strainer	S400427	S400427		S/N 6270716-ON
Case IH	40D		Hydraulic	S140005	S140005	S/N-- 6270750-6270900	S/N 6270716-ON
Case IH	40D		Hydraulic Strainer	S233969	S233969	S/N-- 6270750-6270900	S/N 6270716-ON
Case IH	40D		Hydraulic	S140005	S140005	S/N-- 6270901 & After	S/N 6270716-ON
Case IH	40D		Hydraulic	S530984	S530984	S/N-- 6270901- On,Tank	S/N 6270716-ON
Case IH	40D		Hydraulic	S202018	S202018	Suction	S/N 6270716-ON
Case IH	40D		Lube	L32030	L32030		S/N 6292576-ON
Case IH	40D		Air, Outer	L33920	L33920		S/N 6292576-ON
Case IH	40D		Fuel	A19579	A19579		S/N 6292576-ON
Case IH	40D		Hydraulic	S62434	S62434	Pressure	S/N 6292576-ON
Case IH	40D		Hydraulic	S233969	S233969	Suction	S/N 6292576-ON
Case IH	40D		Hydraulic	L104990	L104990	Tank	S/N 6292576-ON
Case IH	40E		Air, Outer	R29295	R29295		S/N 6292991 ON
Case IH	40E		Fuel	S239799	S239799		S/N 6292991 ON
Case IH	40E		Hydraulic	S109470	S109470		S/N 6292991 ON
Case IH	40E		Hydraulic	L104990	L104990	Tank	S/N 6292991 ON
Case IH	40E		Hydraulic	N9960	N9960	Torque Converter	S/N 6292991 ON
Case IH	40ECYC		Air, Outer	S76237	S76237	F/Case Cummins 6V-352	
Case IH	40ECYC		Air, Outer	AC2900	AC2900	GMC 4-53 Diesel	
Case IH	40ECYC		Air, Outer	S75328	S75328	GMC 4-71 Diesel	
Case IH	40ECYC		Hydraulic	S62434	S62434	Pressure	
Case IH	40ECYC		Hydraulic	S233969	S233969	Suction	
Case IH	40ECYC Series B	Detroit Diesel	Air, Outer	L33920	L33920	Case Engine	S/N 1500-ON
Case IH	40ECYC Series B	Detroit Diesel	Air, Outer	S222020	S222020	Detroit Diesel Engine	S/N 1500-ON

Case IH	40ECYC Series B	Detroit Diesel		Hydraulic	S62434	S62434	Pressure	S/N 1500-ON
Case IH	40ECYC Series B	Detroit Diesel		Hydraulic	S233969	S233969	Suction	S/N 1500-ON
Case IH	40ECYC Series B	Detroit Diesel		Hydraulic	S26293	S26293	Tank	S/N 1500-ON
Case IH	40F			Air, Inner	R36361	R36361		
Case IH	40F			Air, Outer	R29295	R29295		
Case IH	40F			Fuel	S239799	S239799		
Case IH	40F			Hydraulic	S107791	S107791		
Case IH	40F			Hydraulic	S108971	S108971	Suction	
Case IH	40F			Hydraulic	L104990	L104990	Tank	
Case IH	40F			Hydraulic	N9960	N9960	Torque Converter	
Case IH	40XT			Lube	J908616	J908616	Standard	
Case IH	40XT			Lube	J934429	J934429	Premium	
Case IH	40XT			Fuel	J286503	J286503	Spin-on	
Case IH	40XT			Fuel	D139225	D139225	In-line	
Case IH	40XT			Air	222425A1	222425A1	Outer	
Case IH	40XT			Air	222429A1	222429A1	Inner	
Case IH	40XT			Hydraulic	N9025	N9025		
Case IH	430CK			Lube	A7820	A7820		
Case IH	430CK			Lube	G45008	G45008		
Case IH	430CK			Lube	A36206	A36206		
Case IH	430CK			Lube	A306696	A306696		
Case IH	430CK			Fuel	A57228	A57228		
Case IH	430CK			Fuel	A57228	A57228		
Case IH	430CK			Fuel	A52046	A52046		
Case IH	430CK			Fuel	73671	73671	Injection Pump	
Case IH	430CK			Fuel	A35863	A35863	Primary	
Case IH	430CK			Fuel	A7627	A7627	Secondary	
Case IH	430CK			Hydraulic	A27460	A27460		
Case IH	430CK			Hydraulic	G20203	G20203		
Case IH	430CK			Hydraulic	G20203	G20203		
Case IH	430CK			Hydraulic	A39578	A39578		
Case IH	430CK			Hydraulic	A10059	A10059	Pump	
Case IH	430CK			Hydraulic	A42242	A42242	Steering	
Case IH	450B			Lube	A306696	A306696		
Case IH	450B			Air, Inner	D82775	D82775	Inner	
Case IH	450B			Air, Outer	S236468	S236468	Outer	
Case IH	450B			Fuel	A402081	A402081	Kit	
Case IH	450B			Hydraulic	D88730	D88730		
Case IH	450B			Hydraulic	G102201	G102201	Pressure	
Case IH	450B			Hydraulic	D37035	D37035	Suction	
Case IH	450B			Hydraulic	D33557	D33557	Tank	
Case IH	450C	Cummins	4B3.9	Lube	J908650	J908650		
Case IH	450C	Cummins	4B3.9	Air, Inner	A603291	A603291	Inner	
Case IH	450C	Cummins	4B3.9	Air, Outer	A603290	A603290	Outer	

Case IH	450C	Cummins	4B3.9	Fuel	J925274	J925274	Primary
Case IH	450C	Cummins	4B3.9	Fuel	J903640	J903640	Secondary
Case IH	450C	Cummins	4B3.9	Hydraulic	N9025	N9025	
Case IH	450C	Cummins	4B3.9	Hydraulic	D37035	D37035	Suction
Case IH	450C	Cummins	4B3.9	Gasket	238-5218	2385218	
Case IH	455B			Lube	A306696	A306696	
Case IH	455B			Air, Inner	D82775	D82775	Inner
Case IH	455B			Air, Outer	S236468	S236468	Outer
Case IH	455B			Fuel	A402081	A402081	Kit
Case IH	455B			Hydraulic	D88730	D88730	
Case IH	455B			Hydraulic	G102201	G102201	Pressure
Case IH	455B			Hydraulic	D37035	D37035	Suction
Case IH	455B			Hydraulic	D33557	D33557	Tank
Case IH	455C			Lube	J908650	J908650	
Case IH	455C			Air, Inner	A603291	A603291	Inner
Case IH	455C			Air, Outer	A603290	A603290	Outer
Case IH	455C			Fuel	J925274	J925274	Primary
Case IH	455C			Fuel	J903640	J903640	Secondary
Case IH	455C			Hydraulic	N9025	N9025	
Case IH	455C			Hydraulic	D37035	D37035	Suction
Case IH	455C			Gasket	238-5218	2385218	
Case IH	455C			Gasket	N9026	N9026	Hydraulic
Case IH	45B			Lube	A75294	A75294	
Case IH	45B			Air, Inner	S238647	S238647	
Case IH	45B			Air, Outer	S238646	S238646	
Case IH	45B			Fuel Filter	A43344	A43344	Injection Pump
Case IH	45B			Fuel Filter	A44068	A44068	Kit
Case IH	45B			Hydraulic	S140005	S140005	
Case IH	45B			Hydraulic	S202018	S202018	Suction Line
Case IH	45B			Hydraulic	S530984	S530984	Tank
Case IH	45B			Hydraulic	S200193	S200193	Torque Converter
Case IH	480B	Case IH	148B	Lube	G45008	G45008	
Case IH	480B	Case IH	148B	Lube	A306696	A306696	
Case IH	480B	Case IH	148B	Air, Outer	A42274	A42274	
Case IH	480B	Case IH	148B	Fuel	A57228	A57228	
Case IH	480B	Case IH	148B	Fuel	A43870	A43870	Injection Pump
Case IH	480B	Case IH	148B	Fuel	A402081	A402081	Kit
Case IH	480B	Case IH	148B	Fuel	A35863	A35863	Primary
Case IH	480B	Case IH	148B	Fuel	A52046	A52046	Secondary
Case IH	480B	Case IH	148B	Hydraulic	G20203	G20203	
Case IH	480B	Case IH	148B	Hydraulic	A39578	A39578	
Case IH	480B	Case IH	148B	Hydraulic	A10059	A10059	Pump
Case IH	480B	Case IH	148B	Hydraulic	A42242	A42242	Steering
Case IH	480C			Lube	A306696	A306696	
Case IH	480C			Air, Outer	A42274	A42274	

Case IH	480C	Fuel	A43870	A43870	Injection Pump
Case IH	480C	Fuel	A402081	A402081	Secondary
Case IH	480C	Hydraulic	D75831	D75831	
Case IH	480C	Hydraulic	A42242	A42242	Steering
Case IH	480CK	Lube	A306696	A306696	
Case IH	480CK	Fuel	A52046	A52046	
Case IH	480CK	Fuel	73671	73671	Injection Pump
Case IH	480CK	Fuel	A35863	A35863	Primary
Case IH	480CK	Hydraulic	A39578	A39578	
Case IH	480CK	Hydraulic	A10059	A10059	Pump
Case IH	480CK	Hydraulic	A42242	A42242	Steering
Case IH	480D	Lube	A306696	A306696	
Case IH	480D	Air, Outer	A42274	A42274	
Case IH	480D	Fuel	A43870	A43870	Injection Pump
Case IH	480D	Fuel	A402081	A402081	Kit
Case IH	480D	Hydraulic	N9025	N9025	
Case IH	480D	Hydraulic	A42242	A42242	Steering
Case IH	480D-LL	Lube	A306696	A306696	
Case IH	480D-LL	Air, Outer	A42242	A42242	
Case IH	480D-LL	Fuel	A43870	A43870	Injection Pump
Case IH	480D-LL	Fuel	A402081	A402081	Secondary
Case IH	480D-LL	Hydraulic	N9025	N9025	
Case IH	480D-LL	Hydraulic	A42242	A42242	Steering
Case IH	480E	Lube	J908650	J908650	
Case IH	480E	Air, Inner	A603291	A603291	
Case IH	480E	Air, Outer	A603290	A603290	
Case IH	480E	Fuel	J903640	J903640	
Case IH	480E	Fuel	J925274	J925274	
Case IH	480E	Hydraulic	N9025	N9025	
Case IH	480E-LL	Air, Inner	A603291	A603291	
Case IH	480E-LL	Air, Outer	A603290	A603290	
Case IH	480E-LL	Fuel	J925274	J925274	Primary
Case IH	480E-LL	Fuel	J903640	J903640	Secondary
Case IH	480E-LL	Hydraulic	N9025	N9025	
Case IH	480F	Lube	J908650	J908650	
Case IH	480F	Air, Inner	A603291	A603291	
Case IH	480F	Air, Outer	A603290	A603290	
Case IH	480F	Fuel	J925274	J925274	Primary
Case IH	480F	Fuel	J903640	J903640	Secondary
Case IH	480F	Hydraulic	N9025	N9025	
Case IH	480F-LL	Lube	J908650	J908650	
Case IH	480F-LL	Air, Inner	A603291	A603291	
Case IH	480F-LL	Air, Outer	A603290	A603290	
Case IH	480F-LL	Fuel	J925274	J925274	Primary
Case IH	480F-LL	Fuel	J903640	J903640	Secondary

Case IH	480F-LL		Hydraulic	N9025	N9025		
Case IH	500 Crawler		Lube	10060	10060		
Case IH	500 Crawler		Lube	G45008	G45008		
Case IH	500 Crawler		Fuel	A57228	A57228	Secondary	
Case IH	500B		Lube	A36206	A36206		
Case IH	500B		Lube	A36206	A36206		
Case IH	500B		Hydraulic	G20203	G20203		
Case IH	500B		Hydraulic	G20203	G20203		
Case IH	500LK		Lube	A306696	A306696		
Case IH	500LK		Fuel	A52046	A52046	Diesel	
Case IH	500LK		Hydraulic	A27377	A27377		
Case IH	50D	Case IH	Lube	L32030	L32030		S/N 6279926-ON
Case IH	50D	Case IH	Air, Outer	S231996	S231996		S/N 6279926-ON
Case IH	50D	Case IH	Air, Outer	S222047	S222047	Detroit Diesel Engine	S/N 6279926-ON
Case IH	50D	Case IH	Fuel	S105610	S105610		S/N 6279926-ON
Case IH	50D	Case IH	Hydraulic	S104929	S104929	S/N-- 6279926-6280344	S/N 6279926-ON
Case IH	50D	Case IH	Hydraulic	S400428	S400428	S/N-- 6280345 & After	S/N 6279926-ON
Case IH	50D	Case IH	Hydraulic	S233969	S233969	S/N-- 6280345 & After	S/N 6279926-ON
Case IH	50D	Case IH	Hydraulic	S98004	S98004	Steering	S/N 6279926-ON
Case IH	50D	Case IH	Hydraulic	S105892	S105892	Suction	S/N 6279926-ON
Case IH	50E	Case IH	Lube	A75294	A75294		
Case IH	50E	Case IH	Lube	L32030	L32030	Detroit Diesel Engine	
Case IH	50E	Case IH	Air, Outer	S231996	S231996		
Case IH	50E	Case IH	Air, Outer	S222047	S222047	Detroit Diesel Engine	
Case IH	50E	Case IH	Fuel Filter	S105610	S105610	Detroit Diesel Engine	
Case IH	50E	Case IH	Fuel	A43344	A43344	Injection Pump	
Case IH	50E	Case IH	Fuel	A44068	A44068	Kit	
Case IH	50E	Case IH	Hydraulic	S400428	S400428		
Case IH	50E	Case IH	Hydraulic	S140005	S140005	Pressure	
Case IH	50E	Case IH	Hydraulic	S105892	S105892	Suction	
Case IH	50E	Case IH	Hydraulic	S530984	S530984	Tank	
Case IH	50E	Case IH	Hydraulic	S200193	S200193	Torque Converter	
Case IH	50E	Detroit Diesel	Lube	L32030	L32030		
Case IH	50E	Detroit Diesel	Air, Outer	S222047	S222047		
Case IH	50E	Detroit Diesel	Hydraulic	S105892	S105892	Suction	
Case IH	50E	Detroit Diesel	Hydraulic	S200193	S200193	Torque Converter	
Case IH	50EC Series B	Case IH	Air, Outer	L33920	L33920		S/N 550-ON
Case IH	50EC Series B	Case IH	Air, Outer	S222047	S222047	Detroit Diesel Engine	S/N 550-ON
Case IH	50EC Series B	Case IH	Hydraulic	S233969	S233969		S/N 550-ON
Case IH	50EC Series B	Case IH	Hydraulic	S62434	S62434		S/N 550-ON
Case IH	50EC Series B	Case IH	Hydraulic	S26293	S26293	Tank	S/N 550-ON
Case IH	530CK		Lube	A306696	A306696		

Case IH	530CK		Fuel	A35863	A35863	
Case IH	530CK		Fuel	73671	73671	Injection Pump
Case IH	530CK		Fuel	A52046	A52046	Secondary
Case IH	530CK		Hydraulic	G20203	G20203	
Case IH	530CK		Hydraulic	A39578	A39578	Case-O-Matic
Case IH	530CK		Hydraulic	A42242	A42242	Steering
Case IH	550E		Lube	J908650	J908650	
Case IH	550E		Air, Inner	A603291	A603291	
Case IH	550E		Air, Outer	A603290	A603290	
Case IH	550E		Fuel/Water Separator	J912020	J912020	4.4 IN
Case IH	550E		Fuel	J903410	J903410	Primary
Case IH	550E		Fuel	J903640	J903640	Secondary
Case IH	550E		Hydraulic	N9025	N9025	
Case IH	550E		Hydraulic	D37035	D37035	Suction
Case IH	550G		Lube	J908616	J908616	Standard
Case IH	550G		Lube	J934429	J934429	Premium
Case IH	550G		Fuel	J930942	J930942	Before JYG0255794 - Primary
Case IH	550G		Fuel	J903640	J903640	Before JYG0255794 - Secondary
Case IH	550G		Fuel	J930942	J930942	After JYG0255794 - Primary
Case IH	550G		Fuel	J931062	J931062	After JYG0255794 - Secondary
Case IH	550G		Air	A173290	A173290	Before JYG0255794 - Outer
Case IH	550G		Air	A173291	A173291	Before JYG0255794 - Inner
Case IH	550G		Air	128781A1	128781A1	After JYG0255794 - Outer
Case IH	550G		Air	128782A1	128782A1	After JYG0255794 - Inner
Case IH	550G		Hydraulic	1346028C1	1346028C1	
Case IH	550G		Transmission	D37035	D37035	Suction Line
Case IH	550H		Lube	J908616	J908616	Standard
Case IH	550H		Lube	J934429	J934429	Premium
Case IH	550H		Fuel	J930942	J930942	Primary
Case IH	550H		Fuel	J903640	J903640	Secondary
Case IH	550H		Air	222421A1	222421A1	Outer
Case IH	550H		Air	222422A1	222422A1	Inner
Case IH	550H		Hydraulic	1346028C1	1346028C1	
Case IH	550H		Transmission	D37035	D37035	Suction Line
Case IH	580 Super D	G207A	Lube	A306696	A306696	
Case IH	580 Super D	G207A	Lube	A402081	A402081	
Case IH	580 Super D	G207A	Air, Inner	A603291	A603291	
Case IH	580 Super D	G207A	Air, Outer	A603290	A603290	
Case IH	580 Super D	G207A	Air, Outer	A42274	A42274	
Case IH	580 Super D	G207A	Air, Outer	N6777	N6777	
Case IH	580 Super D	G207A	Air, Outer	N6778	N6778	
Case IH	580 Super D	G207A	Cab Air	F44730	F44730	

Case IH	580 Super D	G207A	Fuel	A43870	A43870	
Case IH	580 Super D	G207A	Fuel	A39868	A39868	Primary
Case IH	580 Super D	G207A	Fuel	A39867	A39867	Secondary
Case IH	580 Super D	G207A	Hydraulic	N9025	N9025	
Case IH	580 Super D	G207A	Hydraulic	A42242	A42242	Steering
Case IH	580 Super E	4B3.9	Lube	J908650	J908650	
Case IH	580 Super E	4B3.9	Air, Inner	A603291	A603291	
Case IH	580 Super E	4B3.9	Air, Outer	A603290	A603290	
Case IH	580 Super E	4B3.9	Cab Air	F44730	F44730	
Case IH	580 Super E	4B3.9	Fuel	J925274	J925274	Primary
Case IH	580 Super E	4B3.9	Fuel	J903640	J903640	Secondary
Case IH	580 Super E	4B3.9	Hydraulic	N9025	N9025	
Case IH	580 Super L		Lube	J908650	J908650	
Case IH	580 Super L		Air, Inner	208782A1	208782A1	
Case IH	580 Super L		Air, Outer	208781A1	208781A1	
Case IH	580 Super L		Cab Air	209768A1	209768A1	
Case IH	580 Super L		Fuel	J843760	J843760	
Case IH	580 Super L		Fuel	D305357	D305357	In-Line Fuel
Case IH	580 Super L		Hydraulic	N9025	N9025	
Case IH	580 Super L		Hydraulic	184007A1	184007A1	Transmission
Case IH	580B		Lube	A402081	A402081	
Case IH	580B		Air, Outer	A42274	A42274	
Case IH	580B		Fuel	73671	73671	
Case IH	580B		Fuel	A43870	A43870	
Case IH	580B		Fuel	A52046	A52046	
Case IH	580B		Fuel	A402081	A402081	Kit
Case IH	580B		Hydraulic	A10059	A10059	
Case IH	580B		Hydraulic	D75831	D75831	
Case IH	580B		Hydraulic	A42242	A42242	Steering
Case IH	580C		Lube	A306696	A306696	
Case IH	580C		Air, Outer	A42274	A42274	
Case IH	580C		Fuel	A43870	A43870	Injection Pump
Case IH	580C		Hydraulic	D75831	D75831	
Case IH	580C		Hydraulic	A42242	A42242	Steering
Case IH	580CK		Lube	A306696	A306696	
Case IH	580CK		Air, Outer	A42274	A42274	
Case IH	580CK		Fuel	A402081	A402081	
Case IH	580CK		Fuel	A35863	A35863	
Case IH	580CK		Fuel	73671	73671	Injection Pump
Case IH	580CK		Fuel	A43870	A43870	Injection Pump
Case IH	580CK		Hydraulic	A10059	A10059	
Case IH	580CK		Hydraulic	D75831	D75831	Early Production
Case IH	580CK		Hydraulic	A42242	A42242	Steering
Case IH	580D		Lube	A306696	A306696	N8297800
Case IH	580D		Air, Outer	A603290	A603290	

Case IH	580D			Air, Outer	A603291	A603291	
Case IH	580D			Cab Air	F44730	F44730	
Case IH	580D			Fuel	A402081	A402081	
Case IH	580D			Fuel	A43870	A43870	Injection Pump
Case IH	580D			Fuel	A402081	A402081	Primary
Case IH	580D			Hydraulic	N9025	N9025	
Case IH	580D			Hydraulic	A42242	A42242	Steering
Case IH	580K	Cummins	4-390	Lube	A306696	A306696	
Case IH	580K	Cummins	4-390	Lube	J908650	J908650	
Case IH	580K	Cummins	4-390	Air, Inner	A603291	A603291	
Case IH	580K	Cummins	4-390	Air, Outer	A603290	A603290	
Case IH	580K	Cummins	4-390	Cab Air	R53519	R53519	
Case IH	580K	Cummins	4-390	Fuel	D209225	D209225	In-Line
Case IH	580K	Cummins	4-390	Fuel	D305357	D305357	In-Line Fuel
Case IH	580K	Cummins	4-390	Fuel	A35863	A35863	Primary
Case IH	580K	Cummins	4-390	Fuel	J925274	J925274	Primary
Case IH	580K	Cummins	4-390	Fuel	A52046	A52046	Secondary
Case IH	580K	Cummins	4-390	Fuel	J903640	J903640	Secondary
Case IH	580K	Cummins	4-390	Hydraulic	N9025	N9025	
Case IH	580L			Lube	J908650	J908650	
Case IH	580L			Air, Inner	208782A1	208782A1	
Case IH	580L			Air, Outer	208781A1	208781A1	
Case IH	580L			Cab Air	209768A1	209768A1	
Case IH	580L			Fuel	D305357	D305357	
Case IH	580L			Fuel	J843760	J843760	
Case IH	580L			Fuel	J925274	J925274	
Case IH	580L			Fuel	J903640	J903640	Primary
Case IH	580L			Hydraulic	N9025	N9025	
Case IH	580L			Hydraulic	184008A1	184008A1	Transmission
Case IH	584E			Lube	J908650	J908650	
Case IH	584E			Air, Inner	A603291	A603291	
Case IH	584E			Air, Outer	A603290	A603290	
Case IH	584E			Fuel	J925274	J925274	Primary
Case IH	584E			Fuel	J903640	J903640	Secondary
Case IH	584E			Hydraulic	N9025	N9025	
Case IH	584G			Lube	J908616	J908616	Standard
Case IH	584G			Lube	J934429	J934429	Premium
Case IH	584G			Fuel	J931062	J931062	Spin-on
Case IH	584G			Fuel	194199A1	194199A1	In-line
Case IH	584G			Air	128781A1	128781A1	Outer
Case IH	584G			Air	128782A1	128782A1	Inner
Case IH	584G			Hydraulic	N9025	N9025	Tank
Case IH	584G			Hydraulic	N9026	N9026	O-ring for N9025
Case IH	584G			Transmission	254686A2	254686A2	2WD
Case IH	584G			Transmission	278534A1	278534A1	4WD

Case IH	585B			Hydraulic	D75831	D75831	Early Production
Case IH	585B			Hydraulic	D32220	D32220	Late Production
Case IH	585CD			Lube	A306696	A306696	
Case IH	585CD			Air, Outer	A42274	A42274	
Case IH	585CD			Fuel	A402081	A402081	Primary
Case IH	585CD			Hydraulic	D75831	D75831	C Series
Case IH	585CD			Hydraulic	N9025	N9025	D Series
Case IH	585CD			Hydraulic	A42242	A42242	Steering
Case IH	585E			Lube	J908650	J908650	
Case IH	585E			Air, Inner	A603291	A603291	
Case IH	585E			Air, Outer	A603290	A603290	
Case IH	585E			Fuel	J925274	J925274	Primary
Case IH	585E			Fuel	J903640	J903640	Secondary
Case IH	585E			Hydraulic	N9025	N9025	
Case IH	585G			Lube	J908616	J908616	Standard
Case IH	585G			Lube	J934429	J934429	Premium
Case IH	585G			Fuel	J931062	J931062	Spin-on
Case IH	585G			Fuel	194199A1	194199A1	In-line
Case IH	585G			Air	128781A1	128781A1	Outer
Case IH	585G			Air	128782A1	128782A1	Inner
Case IH	585G			Hydraulic	N9025	N9025	Tank
Case IH	585G			Hydraulic	N9026	N9026	O-ring for N9025
Case IH	585G			Transmission	254686A2	254686A2	2WD
Case IH	585G			Transmission	278534A1	278534A1	4WD
Case IH	586B			Hydraulic	D75831	D75831	Early Production
Case IH	586B			Hydraulic	D32220	D32220	Late Production
Case IH	586CD			Lube	A306696	A306696	
Case IH	586CD			Air, Outer	A42274	A42274	
Case IH	586CD			Fuel	A402081	A402081	Primary
Case IH	586CD			Hydraulic	D75831	D75831	C Series
Case IH	586CD			Hydraulic	N9025	N9025	D Series
Case IH	586CD			Hydraulic	A42242	A42242	Steering
Case IH	586E	Cummins	4B3.9	Lube	J908650	J908650	
Case IH	586E	Cummins	4B3.9	Air, Inner	A603291	A603291	
Case IH	586E	Cummins	4B3.9	Air, Outer	A603290	A603290	
Case IH	586E	Cummins	4B3.9	Fuel	J925274	J925274	Primary
Case IH	586E	Cummins	4B3.9	Fuel	J903640	J903640	Secondary
Case IH	586E	Cummins	4B3.9	Hydraulic	N9025	N9025	
Case IH	586G			Lube	J908616	J908616	Standard
Case IH	586G			Lube	J934429	J934429	Premium
Case IH	586G			Fuel	J931062	J931062	Spin-on
Case IH	586G			Fuel	194199A1	194199A1	In-line
Case IH	586G			Air	128781A1	128781A1	Outer
Case IH	586G			Air	128782A1	128782A1	Inner
Case IH	586G			Hydraulic	N9025	N9025	Tank

Case IH	586G			Hydraulic	N9026	N9026	O-ring for N9025
Case IH	586G			Transmission	254686A2	254686A2	2WD
Case IH	586G			Transmission	278534A1	278534A1	4WD
Case IH	590 Super L			Lube	J908650	J908650	
Case IH	590 Super L			Air, Inner	208782A1	208782A1	
Case IH	590 Super L			Air, Outer	208781A1	208781A1	
Case IH	590 Super L			Cab Air	209768A1	209768A1	
Case IH	590 Super L			Fuel	D305357	D305357	
Case IH	590 Super L			Hydraulic	D309921	D309921	
Case IH	590 Super L			Hydraulic	184008A1	184008A1	Transmission
Case IH	600 Tree Skidder			Lube	A306696	A306696	
Case IH	600 Tree Skidder			Air, Outer	A40866	A40866	
Case IH	600 Tree Skidder			Fuel	A46045	A46045	Kit
Case IH	600 Tree Skidder			Hydraulic	R55043	R55043	
Case IH	600B			Lube	A306696	A306696	
Case IH	600B			Lube	A36206	A36206	
Case IH	600B			Hydraulic	G20203	G20203	
Case IH	60C	Deutz	F4L912	Air, Inner	P850501	P850501	Inner
Case IH	60C	Deutz	F4L912	Air, Outer	P250599	P250599	Outer
Case IH	60C	Deutz	F4L912	Air, Inner	P250566	P250566	Standard, Inner
Case IH	60C	Deutz	F4L912	Air, Outer	P250567	P250567	Standard, Outer
Case IH	60C	Deutz	F4L912	Fuel	P400564	P400564	
Case IH	60C	Deutz	F4L912	Fuel Filter	P50537	P50537	Tank
Case IH	60C	Deutz	F4L912	Hydraulic	P1050586	P1050586	
Case IH	60C	Deutz	F4L912	Hydraulic	P250574	P250574	
Case IH	60C	Deutz	F4L912	Hydraulic	P2050576	P2050576	Tank
Case IH	60CKB			Air, Inner	P250566	P250566	
Case IH	60CKB			Air, Inner	P850501	P850501	
Case IH	60CKB			Air, Outer	P250567	P250567	
Case IH	60CKB			Air, Outer	P250599	P250599	Heavy Duty
Case IH	60CKB			Fuel	P400564	P400564	
Case IH	60CKB			Fuel Filter	P50537	P50537	Tank
Case IH	60CKB			Hydraulic	P1050586	P1050586	
Case IH	60CKB			Hydraulic	P250574	P250574	
Case IH	60CKB			Hydraulic	P2050576	P2050576	Tank
Case IH	60P			Air, Inner	P850501	P850501	Heavy Duty
Case IH	60P			Air, Outer	P250599	P250599	Heavy Duty
Case IH	60P			Air, Inner	P250566	P250566	Standard
Case IH	60P			Air, Outer	P250567	P250567	Standard
Case IH	60P			Fuel	P400564	P400564	
Case IH	60P			Fuel Filter	P50537	P50537	Tank
Case IH	60P			Hydraulic	P1050586	P1050586	
Case IH	60P			Hydraulic	P250574	P250574	

Case IH	60P			Hydraulic	P2050576	P2050576	Tank
Case IH	60P	Deutz	F4L912	Lube	E02432-52	E0243252	
Case IH	60P	Deutz	F4L912	Lube	E0243252	E0243252	
Case IH	60P	Deutz	F4L912	Air, Inner	E02550566	E02550566	
Case IH	60P	Deutz	F4L912	Air, Inner	H08505-01	H0850501	
Case IH	60P	Deutz	F4L912	Air, Outer	E02505-67	E0250567	
Case IH	60P	Deutz	F4L912	Air, Outer	E0250567	E0250567	
Case IH	60P	Deutz	F4L912	Air, Outer	H0850501	H0850501	
Case IH	60P	Deutz	F4L912	Air, Outer	Q02505-99	Q0250599	
Case IH	60P	Deutz	F4L912	Air, Outer	Q0250599	Q0250599	
Case IH	60P	Deutz	F4L912	Fuel	G04005-64	G0400564	
Case IH	60P	Deutz	F4L912	Fuel	G0400564	G0400564	
Case IH	60P	Deutz	F4L912	Hydraulic	N02505-74	N0250574	
Case IH	60P	Deutz	F4L912	Hydraulic	R1010586	R1010586	
Case IH	60PPLB			Air, Inner	P850501	P850501	Heavy Duty
Case IH	60PPLB			Air, Outer	P250599	P250599	Heavy Duty
Case IH	60PPLB			Air, Inner	P250566	P250566	Standard
Case IH	60PPLB			Air, Outer	P250567	P250567	Standard
Case IH	60PPLB			Fuel	P400564	P400564	
Case IH	60PPLB			Fuel Filter	P50537	P50537	Tank
Case IH	60PPLB			Hydraulic	P1050586	P1050586	
Case IH	60PPLB			Hydraulic	P250574	P250574	
Case IH	60PPLB			Hydraulic	P1950550	P1950550	60P-PL-B Only
Case IH	60PPLB			Hydraulic	P2050576	P2050576	Tank
Case IH	60XT			Lube	J908616	J908616	Standard
Case IH	60XT			Lube	J934429	J934429	Premium
Case IH	60XT			Fuel	J286503	J286503	Spin-on
Case IH	60XT			Fuel	D139225	D139225	In-line
Case IH	60XT			Air	222425A1	222425A1	Outer
Case IH	60XT			Air	222429A1	222429A1	Inner
Case IH	60XT			Hydraulic	N9025	N9025	
Case IH	621B			Lube	J908640	J908640	
Case IH	621B			Air, Inner	A47033	A47033	
Case IH	621B			Air, Outer	A47032	A47032	
Case IH	621B			Cab Air	1970006C2	1970006C2	
Case IH	621B			Cab Air	1970098C1	1970098C1	Recirculating
Case IH	621B			Fuel	J925274	J925274	Primary
Case IH	621B			Fuel	J903640	J903640	Secondary
Case IH	621B			Hydraulic	N9025	N9025	
Case IH	621B			Hydraulic	L104990	L104990	Tank
Case IH	621B			Hydraulic	S305020	S305020	Transmission
Case IH	650G			Lube	J908616	J908616	Standard
Case IH	650G			Lube	J934429	J934429	Premium
Case IH	650G			Fuel	J930942	J930942	Before JYG0255794 - Primary
Case IH	650G			Fuel	J903640	J903640	Before JYG0255794 - Secondary

Case IH	650G		Fuel	J930942	J930942	After JYG0255794 - Primary
Case IH	650G		Fuel	J931062	J931062	After JYG0255794 - Secondary
Case IH	650G		Air	222421A1	222421A1	After JYG0216449 - Outer
Case IH	650G		Air	222422A1	222422A1	After JYG0216449 - Inner
Case IH	650G		Air	A47032	A47032	Before JYG0216449 - Outer
Case IH	650G		Air	A47033	A47033	Before JYG0216449 - Inner
Case IH	650G		Hydraulic	1346028C1	1346028C1	
Case IH	650G		Transmission	D37035	D37035	Suction Line
Case IH	650G		Hydraulic	R51643	R51643	Reservoir
Case IH	650H		Lube	J908616	J908616	Standard
Case IH	650H		Lube	J934429	J934429	Premium
Case IH	650H		Fuel	J930942	J930942	Primary
Case IH	650H		Fuel	J931062	J931062	Secondary
Case IH	650H		Air	222421A1	222421A1	Outer
Case IH	650H		Air	222422A1	222422A1	Inner
Case IH	650H		Air	F64318	F64318	Cab
Case IH	650H		Hydraulic	1346028C1	1346028C1	
Case IH	650H		Transmission	D37035	D37035	Suction Line
Case IH	680B		Lube	A23075	A23075	
Case IH	680B		Air, Outer	A40866	A40866	
Case IH	680B		Fuel	A40330	A40330	Injection Pump
Case IH	680B		Fuel	A46045	A46045	Primary
Case IH	680B		Hydraulic	A18789	A18789	
Case IH	680B		Hydraulic	A18061	A18061	Steering
Case IH	680C	301B	Lube	A306696	A306696	
Case IH	680C	301B	Air, Outer	A40866	A40866	
Case IH	680C	301B	Fuel	A46045	A46045	
Case IH	680C	301B	Fuel	A43344	A43344	Injection Pump
Case IH	680C	301B	Hydraulic	L55019	L55019	
Case IH	680C	301B	Hydraulic	A18789	A18789	Tank
Case IH	680C	301B	Hydraulic	L72877	L72877	Tank
Case IH	680CK		Lube	A23075	A23075	
Case IH	680CK		Air, Outer	A42274	A42274	
Case IH	680CK		Fuel	A57228	A57228	
Case IH	680CK		Fuel	A40330	A40330	Injection Pump
Case IH	680CK		Fuel	A22001	A22001	Primary
Case IH	680CK		Fuel	A7627	A7627	Secondary
Case IH	680CK		Hydraulic	D35995	D35995	
Case IH	680CK		Hydraulic	L20869	L20869	S/N-- 9104000-9102280
Case IH	680CK		Hydraulic	A18061	A18061	Steering
Case IH	680CK		Hydraulic	F88379	F88379	To S/N-9104000
Case IH	680E		Lube	A75294	A75294	S/N-- 10018997 ON

Case IH	680E			Lube	A306696	A306696	To S/N-10018997
Case IH	680E			Air, Outer	L35975	L35975	
Case IH	680E			Fuel	A43344	A43344	Injection Pump
Case IH	680E			Fuel	A46045	A46045	Primary
Case IH	680E			Hydraulic	L72877	L72877	Tank
Case IH	680G			Lube	A44081	A44081	
Case IH	680G			Air, Outer	L35975	L35975	
Case IH	680G			Fuel	A43344	A43344	Injection Pump
Case IH	680G			Fuel	A46045	A46045	Kit
Case IH	680G			Hydraulic	L72877	L72877	Tank
Case IH	680H			Lube	A44081	A44081	
Case IH	680H			Air, Outer	D56453	D56453	
Case IH	680H			Cab Air	F44730	F44730	
Case IH	680H			Fuel	A43344	A43344	Injection Pump
Case IH	680H			Hydraulic	A45625	A45625	
Case IH	680H			Hydraulic	D306735	D306735	Transfer Pump
Case IH	680K	Case IH	6.59	Lube	J908640	J908640	
Case IH	680K	Case IH	6.59	Air, Inner	N8403	N8403	
Case IH	680K	Case IH	6.59	Air, Outer	D56453	D56453	
Case IH	680K	Case IH	6.59	Cab Air	F44730	F44730	
Case IH	680K	Case IH	6.59	Fuel	J925274	J925274	Primary
Case IH	680K	Case IH	6.59	Fuel	J903640	J903640	Secondary
Case IH	680K	Case IH	6.59	Hydraulic	A45625	A45625	Kit
Case IH	680L			Lube	J908640	J908640	
Case IH	680L			Air, Inner	A47033	A47033	
Case IH	680L			Air, Outer	A47032	A47032	
Case IH	680L			Cab Air	F44730	F44730	
Case IH	680L			Fuel	J925274	J925274	Primary
Case IH	680L			Fuel	J903640	J903640	Secondary
Case IH	680L			Hydraulic	2029230C1	2029230C1	
Case IH	680L			Hydraulic	D306735	D306735	Transfer Pump
Case IH	686G Series 1 + 2			Lube	J908616	J908616	Standard
Case IH	686G Series 1 + 2			Lube	J934429	J934429	Premium
Case IH	686G Series 1 + 2			Fuel	J931062	J931062	Spin-on
Case IH	686G Series 1 + 2			Fuel	194199A1	194199A1	In-line
Case IH	686G Series 1 + 2			Air	133720A1	133720A1	Naturally Asp - Outer
Case IH	686G Series 1 + 2			Air	133721A1	133721A1	Naturally Asp - Inner
Case IH	686G Series 1 + 2			Air	222421A1	222421A1	Turbo - Outer
Case IH	686G Series 1 + 2			Air	366557A1	366557A1	Turbo - Inner
Case IH	686G Series 1 + 2			Hydraulic	H439069	H439069	

Case IH	686G Series 1 + 2		Transmission	314016A1	314016A1	
Case IH	686GXR Series 1 + 2		Lube	J908616	J908616	Standard
Case IH	686GXR Series 1 + 2		Lube	J934429	J934429	Premium
Case IH	686GXR Series 1 + 2		Fuel	J931062	J931062	Spin-on
Case IH	686GXR Series 1 + 2		Fuel	194199A1	194199A1	In-line
Case IH	686GXR Series 1 + 2		Air	133720A1	133720A1	Naturally Asp - Outer
Case IH	686GXR Series 1 + 2		Air	133721A1	133721A1	Naturally Asp - Inner
Case IH	686GXR Series 1 + 2		Air	222421A1	222421A1	Turbo - Outer
Case IH	686GXR Series 1 + 2		Air	366557A1	366557A1	Turbo - Inner
Case IH	686GXR Series 1 + 2		Hydraulic	H439069	H439069	
Case IH	686GXR Series 1 + 2		Transmission	314016A1	314016A1	
Case IH	688G Series 2		Lube	J908616	J908616	Standard
Case IH	688G Series 2		Lube	J934429	J934429	Premium
Case IH	688G Series 2		Fuel	J931062	J931062	Spin-on
Case IH	688G Series 2		Fuel	194199A1	194199A1	In-line
Case IH	688G Series 2		Air	133720A1	133720A1	Naturally Asp - Outer
Case IH	688G Series 2		Air	133721A1	133721A1	Naturally Asp - Inner
Case IH	688G Series 2		Air	222421A1	222421A1	Turbo - Outer
Case IH	688G Series 2		Air	366557A1	366557A1	Turbo - Inner
Case IH	688G Series 2		Hydraulic	H439069	H439069	
Case IH	688G Series 2		Transmission	314016A1	314016A1	
Case IH	689G		Lube	3214797R1	3214797R1	
Case IH	689G		Fuel	218100A1	218100A1	
Case IH	689G		Air	D56453	D56453	
Case IH	689G		Hydraulic	310029A1	310029A1	
Case IH	689G		Transmission	314016A1	314016A1	
Case IH	689G		Coolant	310244A1	310244A1	
Case IH	70+4	207	Lube	A306696	A306696	
Case IH	70+4	207	Air, Outer	A42274	A42274	
Case IH	70+4	207	Fuel	A402081	A402081	Primary
Case IH	70+4	207	Hydraulic	H340054	H340054	
Case IH	70CKB		Air, Inner	P850501	P850501	Heavy Duty
Case IH	70CKB		Air, Outer	P250599	P250599	Heavy Duty
Case IH	70CKB		Air, Inner	P250566	P250566	Standard
Case IH	70CKB		Air, Outer	P250567	P250567	Standard
Case IH	70CKB		Fuel	P400564	P400564	
Case IH	70CKB		Fuel Filter	P50537	P50537	Tank
Case IH	70CKB		Hydraulic	P1050586	P1050586	

Case IH	70CKB			Hydraulic	P250574	P250574	
Case IH	70CKB			Hydraulic	P2050576	P2050576	Tank
Case IH	70XT			Lube	J908616	J908616	Standard
Case IH	70XT			Lube	J934429	J934429	Premium
Case IH	70XT			Fuel	J286503	J286503	Spin-on
Case IH	70XT			Fuel	D139225	D139225	In-line
Case IH	70XT			Air	222421A1	222421A1	Outer
Case IH	70XT			Air	222422A1	222422A1	Inner
Case IH	70XT			Hydraulic	N9025	N9025	
Case IH	721B			Lube	J919562	J919562	
Case IH	721B			Air, Inner	S238647	S238647	
Case IH	721B			Air, Outer	S238646	S238646	
Case IH	721B			Cab Air	1970006C2	1970006C2	
Case IH	721B			Cab Air	1970098C1	1970098C1	
Case IH	721B			Fuel	J903640	J903640	Secondary
Case IH	721B			Hydraulic	N9025	N9025	
Case IH	721B			Hydraulic	L104990	L104990	Tank
Case IH	721B			Hydraulic	185501A1	185501A1	Transmission
Case IH	721B			Hydraulic	S305020	S305020	Transmission
Case IH	721B			Coolant	A77544	A77544	
Case IH	75C			Lube	P2050575	P2050575	
Case IH	75C			Air, Inner	P250581	P250581	Heavy Duty
Case IH	75C			Air, Outer	P850510	P850510	Heavy Duty
Case IH	75C			Air, Inner	P450544	P450544	Standard
Case IH	75C			Air, Outer	P450543	P450543	Standard
Case IH	75C			Fuel	P400564	P400564	
Case IH	75C			Fuel Filter	P50537	P50537	Tank
Case IH	75C			Hydraulic	P1050586	P1050586	
Case IH	75C			Hydraulic	P250574	P250574	
Case IH	75C			Hydraulic	P2050576	P2050576	Tank
Case IH	75P			Lube	P2050575	P2050575	
Case IH	75P			Air, Inner	P250581	P250581	Heavy Duty
Case IH	75P			Air, Outer	P850510	P850510	Heavy Duty
Case IH	75P			Air, Inner	P450544	P450544	Standard
Case IH	75P			Air, Outer	P450543	P450543	Standard
Case IH	75P			Fuel	P400564	P400564	
Case IH	75P			Fuel Filter	P50537	P50537	Tank
Case IH	75P			Hydraulic	P1050586	P1050586	
Case IH	75P			Hydraulic	P250574	P250574	
Case IH	75P			Hydraulic	P400580	P400580	75P Only
Case IH	75P			Hydraulic	P2050576	P2050576	Tank
Case IH	75P	Deutz	F5L912	Lube	K0400521	K0400521	
Case IH	75P	Deutz	F5L912	Lube	K08508-88	K0850888	
Case IH	75P	Deutz	F5L912	Air, Inner	H10505-78	H1050578	
Case IH	75P	Deutz	F5L912	Air, Outer	S0850510	S0850510	

Case IH	75P	Deutz	F5L912	Air, Outer	V0250581	V0250581	
Case IH	75P	Deutz	F5L912	Air, Outer	V04505-43	V0450543	
Case IH	75P	Deutz	F5L912	Air, Outer	V0450543	V0450543	
Case IH	75P	Deutz	F5L912	Fuel	G04005-64	G0400564	
Case IH	75P	Deutz	F5L912	Hydraulic	N02505-74	N0250574	
Case IH	75P	Deutz	F5L912	Hydraulic	N0250574	N0250574	
Case IH	75P	Deutz	F5L912	Hydraulic	Z0400580	Z0400580	
Case IH	75P	Deutz	F6L912	Lube	K0400521	K0400521	
Case IH	75P	Deutz	F6L912	Air, Inner	H1010578	H1010578	
Case IH	75P	Deutz	F6L912	Air, Outer	S0850510	S0850510	
Case IH	75P	Deutz	F6L912	Air, Outer	V0250581	V0250581	
Case IH	75P	Deutz	F6L912	Air, Outer	V0450543	V0450543	
Case IH	75P	Deutz	F6L912	Fuel	400526	400526	
Case IH	75P	Deutz	F6L912	Hydraulic	N0250574	N0250574	
Case IH	75P	Deutz	F6L912	Hydraulic	Z0400580	Z0400580	
Case IH	75PB			Lube	P2050575	P2050575	
Case IH	75PB			Air, Inner	P250581	P250581	Heavy Duty
Case IH	75PB			Air, Outer	P850510	P850510	Heavy Duty
Case IH	75PB			Air, Inner	P450544	P450544	Standard
Case IH	75PB			Air, Outer	P450543	P450543	Standard
Case IH	75PB			Fuel	P400564	P400564	
Case IH	75PB			Fuel Filter	P50537	P50537	Tank
Case IH	75PB			Hydraulic	P1050586	P1050586	
Case IH	75PB			Hydraulic	P250574	P250574	
Case IH	75PB			Hydraulic	P400580	P400580	75P Only
Case IH	75PB			Hydraulic	P2050576	P2050576	Tank
Case IH	75XT			Lube	J908616	J908616	Standard
Case IH	75XT			Lube	J934429	J934429	Premium
Case IH	75XT			Fuel	J286503	J286503	Spin-on
Case IH	75XT			Fuel	D139225	D139225	In-line
Case IH	75XT			Air	222425A1	222425A1	Outer
Case IH	75XT			Air	222429A1	222429A1	Inner
Case IH	75XT			Hydraulic	222759A1	222759A1	Charge
Case IH	75XT			Hydraulic	N9025	N9025	Return
Case IH	821B	Cummins	6T8.3	Lube	J919562	J919562	
Case IH	821B	Cummins	6T8.3	Air, Inner	S238647	S238647	
Case IH	821B	Cummins	6T8.3	Air, Outer	S238646	S238646	
Case IH	821B	Cummins	6T8.3	Cab Air	1970006C2	1970006C2	
Case IH	821B	Cummins	6T8.3	Cab Air	1970098C1	1970098C1	Recirculating
Case IH	821B	Cummins	6T8.3	Fuel	J925274	J925274	Primary
Case IH	821B	Cummins	6T8.3	Fuel	J903640	J903640	Secondary
Case IH	821B	Cummins	6T8.3	Hydraulic	N9025	N9025	
Case IH	821B	Cummins	6T8.3	Hydraulic	L104990	L104990	Tank
Case IH	821B	Cummins	6T8.3	Hydraulic	S305020	S305020	Transmission
Case IH	821B	Cummins	6T8.3	Coolant	A77544	A77544	

Case IH	825 Tree Skidder			Lube	A306696	A306696	
Case IH	825 Tree Skidder			Air, Outer	L33920	L33920	
Case IH	825 Tree Skidder			Fuel	A46045	A46045	Kit
Case IH	825 Tree Skidder			Hydraulic	R55043	R55043	
Case IH	850B			Lube	A75294	A75294	
Case IH	850B			Air, Inner	D78336	D78336	Non-Turbo
Case IH	850B			Air, Outer	A40866	A40866	Non-Turbo
Case IH	850B			Air, Inner	D78325	D78325	Turbo
Case IH	850B			Air, Outer	D78326	D78326	Turbo
Case IH	850B			Fuel	A43344	A43344	Injection Pump
Case IH	850B			Fuel	A46045	A46045	Kit
Case IH	850B			Hydraulic	R55043	R55043	
Case IH	850B			Hydraulic	G102201	G102201	Pressure
Case IH	850B			Hydraulic	D32220	D32220	Suction
Case IH	850B			Hydraulic	D33557	D33557	Tank
Case IH	850C			Lube	A44081	A44081	
Case IH	850C			Cab Air	F64318	F64318	
Case IH	850C			Air, Inner	D78336	D78336	Non-Turbo
Case IH	850C			Air, Outer	D80480	D80480	Non-Turbo
Case IH	850C			Air, Inner	D78325	D78325	Turbo
Case IH	850C			Air, Outer	D78326	D78326	Turbo
Case IH	850C			Fuel	A43344	A43344	Injection Pump
Case IH	850C			Fuel	A46045	A46045	Kit
Case IH	850C			Hydraulic	R55043	R55043	
Case IH	850C			Hydraulic	G102201	G102201	Pressure
Case IH	850C			Hydraulic	D32220	D32220	Suction
Case IH	850C			Hydraulic	D33557	D33557	Tank
Case IH	850D	Case IH	A336BD	Cab Air	F64318	F64318	
Case IH	850D	Case IH	A336BD	Air, Inner	A47033	A47033	Inner
Case IH	850D	Case IH	A336BD	Air, Outer	A47032	A47032	Outer
Case IH	850D	Case IH	A336BD	Fuel	J925274	J925274	Primary
Case IH	850D	Case IH	A336BD	Fuel	J903640	J903640	Secondary
Case IH	850D	Case IH	A336BD	Hydraulic	N9025	N9025	
Case IH	850D	Case IH	A336BD	Hydraulic	R55043	R55043	Reservoir
Case IH	850D	Case IH	A336BD	Hydraulic	D32220	D32220	Suction
Case IH	850D	Case IH	A336BD	Gasket	N9026	N9026	Hydraulic
Case IH	850E	Cummins	6B5.9	Lube	J908640	J908640	
Case IH	850E	Cummins	6B5.9	Cab Air	F64318	F64318	
Case IH	850E	Cummins	6B5.9	Air, Inner	A47033	A47033	Inner
Case IH	850E	Cummins	6B5.9	Air, Outer	A47032	A47032	Outer
Case IH	850E	Cummins	6B5.9	Fuel Primary	J925274	J925274	Primary
Case IH	850E	Cummins	6B5.9	Fuel Secondary	J903640	J903640	Secondary
Case IH	850E	Cummins	6B5.9	Hydraulic	N9025	N9025	

Case IH	850E	Cummins	6B5.9	Hydraulic	R55043	R55043	Reservoir
Case IH	850E	Cummins	6B5.9	Hydraulic	D37035	D37035	Suction
Case IH	850E	Cummins	6B5.9	Gasket	N9026	N9026	Hydraulic
Case IH	850G	Cummins	6BT5.9	Lube	J908640	J908640	
Case IH	850G	Cummins	6BT5.9	Cab Air	F64318	F64318	
Case IH	850G	Cummins	6BT5.9	Air, Inner	A47033	A47033	Inner
Case IH	850G	Cummins	6BT5.9	Air, Outer	A47032	A47032	Outer
Case IH	850G	Cummins	6BT5.9	Fuel Filter	R57888	R57888	In-Line
Case IH	850G	Cummins	6BT5.9	Fuel	J925274	J925274	Primary
Case IH	850G	Cummins	6BT5.9	Fuel	J903640	J903640	Secondary
Case IH	850G	Cummins	6BT5.9	Hydraulic	N9025	N9025	Reservoir
Case IH	850G	Cummins	6BT5.9	Hydraulic	R55043	R55043	Reservoir
Case IH	850G	Cummins	6BT5.9	Hydraulic	D37035	D37035	Suction
Case IH	850G			Lube	J937345	J937345	Standard
Case IH	850G			Lube	J934430	J934430	Premium
Case IH	850G			Fuel	J930942	J930942	Primary
Case IH	850G			Fuel	J903640	J903640	Secondary
Case IH	850G			Air	A47032	A47032	Before JYG0254015 - Outer
Case IH	850G			Air	A47033	A47033	Before JYG0254015 - Inner
Case IH	850G			Air	187471A1	187471A1	After JYG0254015 - Outer
Case IH	850G			Air	187472A1	187472A1	After JYG0254015 - Inner
Case IH	850G			Air	F64318	F64318	Cab
Case IH	850G			Hydraulic	1346028C1	1346028C1	
Case IH	850G			Hydraulic	R51643	R51643	Reservoir
Case IH	850G			Transmission	D37035	D37035	Suction Line
Case IH	850H			Lube	J937345	J937345	Standard
Case IH	850H			Lube	J934430	J934430	Premium
Case IH	850H			Fuel	J930942	J930942	Primary
Case IH	850H			Fuel	J903640	J903640	Secondary
Case IH	850H			Air	187471A1	187471A1	Outer
Case IH	850H			Air	187472A1	187472A1	Inner
Case IH	850H			Air	F64318	F64318	Cab
Case IH	850H			Hydraulic	1346028C1	1346028C1	
Case IH	850H			Transmission	D37035	D37035	Suction Line
Case IH	850K			Lube	J937743	J937743	
Case IH	850K			Fuel	J930942	J930942	Primary
Case IH	850K			Fuel	J931063	J931063	Secondary
Case IH	850K			Fuel	194199A1	194199A1	In-line
Case IH	850K			Hydraulic	402652A1	402652A1	
Case IH	850K			Transmission	254353A1	254353A1	
Case IH	850K			Air	392120A1	392120A1	Outer
Case IH	850K			Air	392121A1	392121A1	Inner
Case IH	850K			Air	76067303	76067303	Cab

Case IH	850K			Coolant	392120A1	392120A1	
Case IH	855C			Lube	A44081	A44081	
Case IH	855C			Cab Air	F64318	F64318	
Case IH	855C			Air, Inner	D78336	D78336	Non-Turbo
Case IH	855C			Air, Outer	D80480	D80480	Non-Turbo
Case IH	855C			Air, Inner	D78325	D78325	Turbo
Case IH	855C			Air, Outer	D78326	D78326	Turbo
Case IH	855C			Fuel	A43344	A43344	Injection Pump
Case IH	855C			Fuel	A46045	A46045	Kit
Case IH	855C			Hydraulic	R55043	R55043	
Case IH	855C			Hydraulic	G102201	G102201	Pressure
Case IH	855C			Hydraulic	D32220	D32220	Suction
Case IH	855C			Hydraulic	D33557	D33557	Tank
Case IH	855D			Lube	J908640	J908640	
Case IH	855D			Air, Inner	A47033	A47033	
Case IH	855D			Air, Outer	A47032	A47032	
Case IH	855D			Cab Air	F64318	F64318	
Case IH	855D			Fuel/Water Separator-4.4"	J912020	J912020	
Case IH	855D			Fuel/Water Separator, Primary	A77470	A77470	1991-0N
Case IH	855D			Fuel	J903410	J903410	Primary
Case IH	855D			Fuel	J903640	J903640	Secondary
Case IH	855D			Hydraulic	N9025	N9025	
Case IH	855D			Hydraulic	R55043	R55043	Reservoir
Case IH	855D			Hydraulic	D32220	D32220	Suction
Case IH	855E	Cummins	6B5.9	Lube	J908640	J908640	
Case IH	855E	Cummins	6B5.9	Lube	J908640	J908640	
Case IH	855E	Cummins	6B5.9	Air, Inner	A47033	A47033	
Case IH	855E	Cummins	6B5.9	Air, Outer	A47032	A47032	
Case IH	855E	Cummins	6B5.9	Cab Air	F44730	F44730	
Case IH	855E	Cummins	6B5.9	Cab Air	F64318	F64318	
Case IH	855E	Cummins	6B5.9	Air, Inner	A47033	A47033	Inner
Case IH	855E	Cummins	6B5.9	Air, Outer	A47032	A47032	Outer
Case IH	855E	Cummins	6B5.9	Fuel	J925274	J925274	Primary
Case IH	855E	Cummins	6B5.9	Fuel	J925274	J925274	Primary
Case IH	855E	Cummins	6B5.9	Fuel	J903640	J903640	Secondary
Case IH	855E	Cummins	6B5.9	Fuel	J903640	J903640	Secondary
Case IH	855E	Cummins	6B5.9	Hydraulic	2029230C1	2029230C1	
Case IH	855E	Cummins	6B5.9	Hydraulic	N9025	N9025	
Case IH	855E	Cummins	6B5.9	Hydraulic	R55043	R55043	Reservoir
Case IH	855E	Cummins	6B5.9	Hydraulic	D37035	D37035	Suction
Case IH	855E	Cummins	6B5.9	Hydraulic	D306735	D306735	Transfer Pump
Case IH	855E	Cummins	6B5.9	Gasket	N9026	N9026	Hydraulic
Case IH	85CKB			Lube	P2050575	P2050575	
Case IH	85CKB			Air, Inner	P450544	P450544	

Case IH	85CKB	Air, Outer	P450543	P450543	
Case IH	85CKB	Air, Inner	P250581	P250581	Heavy Duty
Case IH	85CKB	Air, Outer	P850510	P850510	Heavy Duty
Case IH	85CKB	Fuel	P400564	P400564	
Case IH	85CKB	Fuel Filter	P50537	P50537	Tank
Case IH	85CKB	Hydraulic	P1050586	P1050586	
Case IH	85CKB	Hydraulic	P250574	P250574	
Case IH	85CKB	Hydraulic	P2050576	P2050576	Tank
Case IH	85XT	Lube	J908616	J908616	Standard
Case IH	85XT	Lube	J934429	J934429	Premium
Case IH	85XT	Fuel	J286503	J286503	Spin-on
Case IH	85XT	Fuel	D139225	D139225	In-line
Case IH	85XT	Air	222425A1	222425A1	Outer
Case IH	85XT	Air	222429A1	222429A1	Inner
Case IH	85XT	Hydraulic	222759A1	222759A1	Charge
Case IH	85XT	Hydraulic	N9025	N9025	Return
Case IH	880B	Lube	A75294	A75294	
Case IH	880B	Air, Outer	D56453	D56453	
Case IH	880B	Fuel	A43344	A43344	Injection Pump
Case IH	880B	Fuel	A46045	A46045	Kit
Case IH	880B	Hydraulic	S62434	S62434	
Case IH	880B	Hydraulic	S233969	S233969	Strainer
Case IH	880B	Hydraulic	S520507	S520507	Tank
Case IH	880C	Lube	A75294	A75294	
Case IH	880C	Air, Outer	D56453	D56453	S/N-6205253 ON
Case IH	880C	Air, Inner	A160746	A160746	To S/N-6205253
Case IH	880C	Air, Outer	A160745	A160745	To S/N-6205253
Case IH	880C	Fuel	A43344	A43344	Injection Pump
Case IH	880C	Fuel	A44068	A44068	Kit
Case IH	880C	Hydraulic	S233969	S233969	S/N-6205236 ON Front
Case IH	880C	Hydraulic	S107791	S107791	S/N-6205236 ON Rear
Case IH	880C	Hydraulic	S520507	S520507	S/N-6205236 ON Tank
Case IH	880C	Hydraulic	S108971	S108971	Suction Line
Case IH	880C	Hydraulic	S107791	S107791	To S/N-6205236 Front
Case IH	880C	Hydraulic	S62434	S62434	To S/N-6205236 Rear
Case IH	880D	Lube	J908640	J908640	
Case IH	880D	Air, Inner	R36361	R36361	
Case IH	880D	Air, Outer	R29295	R29295	
Case IH	880D	Fuel Primary	J925274	J925274	Primary
Case IH	880D	Fuel	J903640	J903640	Secondary
Case IH	880D	Hydraulic	S107791	S107791	
Case IH	880D	Hydraulic	S233969	S233969	Oil Screen
Case IH	880D	Hydraulic	S108971	S108971	Suction Line
Case IH	880D	Hydraulic	S530984	S530984	Tank
Case IH	880R	Lube	A75294	A75294	

Case IH	880R	Air, Outer	A40866	A40866	
Case IH	880R	Fuel	A43344	A43344	Injection Pump
Case IH	880R	Fuel	A46045	A46045	Kit
Case IH	880R	Hydraulic	S233969	S233969	
Case IH	880R	Hydraulic	S62434	S62434	
Case IH	880R	Hydraulic	S220566	S220566	Tank
Case IH	9007B	Lube	366115A1	366115A1	
Case IH	9007B	Fuel	413965A1	413965A1	
Case IH	9007B	Air	167815A1	167815A1	Outer
Case IH	9007B	Hydraulic	167704A1	167704A1	Tank
Case IH	9007B	Hydraulic	168004A1	168004A1	Return Line
Case IH	9007B	Hydraulic	153233A1	153233A1	Pilot Line
Case IH	9007B	Hydraulic	163279A1	163279A1	Auxiliary
Case IH	9010B	Lube	J908650	J908650	
Case IH	9010B	Air, Inner	400482A1	400482A1	
Case IH	9010B	Air, Outer	400478A1	400478A1	
Case IH	9010B	Fuel	D305357	D305357	In-Line
Case IH	9010B	Fuel	J925274	J925274	Primary
Case IH	9010B	Fuel	J903640	J903640	Secondary
Case IH	9010B	Fuel	400306A1	400306A1	Tank
Case IH	9010B	Hydraulic	409282A1	409282A1	Bypass
Case IH	9010B	Hydraulic	404052A1	404052A1	In-Line
Case IH	9010B	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9010B	Hydraulic	400794A1	400794A1	Return Line
Case IH	9010B	Hydraulic	403190A1	403190A1	Tank
Case IH	9020B	Lube	J908650	J908650	
Case IH	9020B	Air, Inner	400482A1	400482A1	
Case IH	9020B	Air, Outer	400478A1	400478A1	
Case IH	9020B	Fuel	D305357	D305357	In-Line
Case IH	9020B	Fuel	J925274	J925274	Primary
Case IH	9020B	Fuel	J903640	J903640	Secondary
Case IH	9020B	Fuel	400306A1	400306A1	Tank
Case IH	9020B	Hydraulic	409282A1	409282A1	Bypass
Case IH	9020B	Hydraulic	404052A1	404052A1	In-Line
Case IH	9020B	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9020B	Hydraulic	400794A1	400794A1	Return Line
Case IH	9020B	Hydraulic	403190A1	403190A1	Tank
Case IH	9030B	Lube	J908640	J908640	
Case IH	9030B	Air, Inner	N6660	N6660	
Case IH	9030B	Air, Outer	501863A1	501863A1	
Case IH	9030B	Fuel	D305357	D305357	In-Line
Case IH	9030B	Fuel	J925274	J925274	Primary
Case IH	9030B	Fuel	J903640	J903640	Secondary
Case IH	9030B	Fuel	400306A1	400306A1	Tank
Case IH	9030B	Hydraulic	409282A1	409282A1	Bypass

Case IH	9030B	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9030B	Hydraulic	400794A1	400794A1	Return Line
Case IH	9030B	Hydraulic	409274A1	409274A1	Tank
Case IH	9040B	Lube	J919562	J919562	
Case IH	9040B	Air, Inner	402097A1	402097A1	
Case IH	9040B	Air, Outer	400783A1	400783A1	
Case IH	9040B	Fuel	D305357	D305357	In-Line
Case IH	9040B	Fuel	J925274	J925274	Primary
Case IH	9040B	Fuel	J903640	J903640	Secondary
Case IH	9040B	Fuel	400306A1	400306A1	Tank
Case IH	9040B	Hydraulic	409282A1	409282A1	Bypass
Case IH	9040B	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9040B	Hydraulic	400794A1	400794A1	Return Line
Case IH	9040B	Hydraulic	409274A1	409274A1	Tank
Case IH	9040B	Coolant	A77544	A77544	
Case IH	9050B	Lube	402097A1	402097A1	
Case IH	9050B	Air, Inner	402097A1	402097A1	
Case IH	9050B	Air, Outer	400783A1	400783A1	
Case IH	9050B	Fuel	ME069671	ME069671	FFWS
Case IH	9050B	Fuel	400306A1	400306A1	Tank
Case IH	9050B	Hydraulic	403233A1	403233A1	Pilot Line
Case IH	9050B	Hydraulic	400794A1	400794A1	Return Line
Case IH	9050B	Hydraulic	403344A1	403344A1	Tank
Case IH	9050B	Coolant	A77544	A77544	
Case IH	90C	Lube	P2050575	P2050575	
Case IH	90C	Air, Inner	P250581	P250581	
Case IH	90C	Air, Inner	P450544	P450544	
Case IH	90C	Air, Outer	P450543	P450543	
Case IH	90C	Air, Outer	P850510	P850510	
Case IH	90C	Fuel	P400564	P400564	
Case IH	90C	Fuel Filter	P50537	P50537	Tank
Case IH	90C	Hydraulic	P1050586	P1050586	
Case IH	90C	Hydraulic	P250574	P250574	
Case IH	90C	Hydraulic	P2050576	P2050576	Tank
Case IH	90P	Lube	L32030	L32030	
Case IH	90P	Lube	P2050575	P2050575	
Case IH	90P	Air, Inner	P250581	P250581	
Case IH	90P	Air, Inner	P450544	P450544	
Case IH	90P	Air, Outer	P450543	P450543	
Case IH	90P	Air, Outer	P850510	P850510	
Case IH	90P	Fuel	S105610	S105610	
Case IH	90P	Fuel	P400564	P400564	
Case IH	90P	Fuel Filter	P50537	P50537	Tank
Case IH	90P	Hydraulic	S104929	S104929	
Case IH	90P	Hydraulic	P1050586	P1050586	

Case IH	90P			Hydraulic	P250574	P250574	
Case IH	90P			Hydraulic	P400580	P400580	90P,90P-B Only
Case IH	90P			Hydraulic	S88677	S88677	Tank
Case IH	90P			Hydraulic	P2050576	P2050576	Tank
Case IH	90P			Hydraulic	L47739	L47739	Torque Converter
Case IH	90P	Deutz	F5L912	Lube	E02432-52	E0243252	
Case IH	90P	Deutz	F5L912	Lube	K0400521	K0400521	
Case IH	90P	Deutz	F5L912	Lube	K08505-88	K0850588	
Case IH	90P	Deutz	F5L912	Air, Inner	H1010578	H1010578	
Case IH	90P	Deutz	F5L912	Air, Inner	H10505-78	H1050578	
Case IH	90P	Deutz	F5L912	Air, Inner	V02505-81	V0250581	
Case IH	90P	Deutz	F5L912	Air, Outer	S0850510	S0850510	
Case IH	90P	Deutz	F5L912	Air, Outer	T19505-55	T1950555	
Case IH	90P	Deutz	F5L912	Air, Outer	V0250581	V0250581	
Case IH	90P	Deutz	F5L912	Air, Outer	V04505-43	V0450543	
Case IH	90P	Deutz	F5L912	Air, Outer	V0450543	V0450543	
Case IH	90P	Deutz	F5L912	Fuel	G04005-64	G0400564	
Case IH	90P	Deutz	F5L912	Hydraulic	N02505-74	N0250574	
Case IH	90P	Deutz	F5L912	Hydraulic	N0250574	N0250574	
Case IH	90P	Deutz	F5L912	Hydraulic	Z0400580	Z0400580	
Case IH	90P	Deutz	F6L912	Lube	E02432-52	E0243252	
Case IH	90P	Deutz	F6L912	Lube	K0400521	K0400521	
Case IH	90P	Deutz	F6L912	Lube	K08505-88	K0850588	
Case IH	90P	Deutz	F6L912	Air, Inner	H1010578	H1010578	
Case IH	90P	Deutz	F6L912	Air, Inner	H10505-78	H1050578	
Case IH	90P	Deutz	F6L912	Air, Inner	V02505-81	V0250581	
Case IH	90P	Deutz	F6L912	Air, Outer	S0850510	S0850510	
Case IH	90P	Deutz	F6L912	Air, Outer	T19505-55	T1950555	
Case IH	90P	Deutz	F6L912	Air, Outer	V0250581	V0250581	
Case IH	90P	Deutz	F6L912	Air, Outer	V04505-43	V0450543	
Case IH	90P	Deutz	F6L912	Air, Outer	V0450543	V0450543	
Case IH	90P	Deutz	F6L912	Fuel	G04005-64	G0400564	
Case IH	90P	Deutz	F6L912	Hydraulic	N02505-74	N0250574	
Case IH	90P	Deutz	F6L912	Hydraulic	N0250574	N0250574	
Case IH	90P	Deutz	F6L912	Hydraulic	Z0400580	Z0400580	
Case IH	90PB			Lube	P2050575	P2050575	
Case IH	90PB			Air, Inner	P250581	P250581	
Case IH	90PB			Air, Inner	P450544	P450544	
Case IH	90PB			Air, Outer	P450543	P450543	
Case IH	90PB			Air, Outer	P850510	P850510	
Case IH	90PB			Fuel	P400564	P400564	
Case IH	90PB			Fuel Filter	P50537	P50537	Tank
Case IH	90PB			Hydraulic	P1050586	P1050586	
Case IH	90PB			Hydraulic	P250574	P250574	
Case IH	90PB			Hydraulic	P400580	P400580	90P,90P-B Only

Case IH	90PB			Hydraulic	P2050576	P2050576	Tank
Case IH	90XT			Lube	J908616	J908616	Standard
Case IH	90XT			Lube	J934429	J934429	Premium
Case IH	90XT			Fuel	J286503	J286503	Spin-on
Case IH	90XT			Fuel	D139225	D139225	In-line
Case IH	90XT			Air	222421A1	222421A1	Outer
Case IH	90XT			Air	222422A1	222422A1	Inner
Case IH	90XT			Hydraulic	244913A1	244913A1	Element
Case IH	90XT			Hydraulic	N9025	N9025	Return
Case IH	90XT			Hydraulic	222759A1	222759A1	Charge
Case IH	921B	Cummins	LTA10C	Lube	907101T1	907101T1	
Case IH	921B	Cummins	LTA10C	Air, Inner	627976C1	627976C1	
Case IH	921B	Cummins	LTA10C	Air, Outer	627975C3	627975C3	
Case IH	921B	Cummins	LTA10C	Cab Air	1970006C2	1970006C2	
Case IH	921B	Cummins	LTA10C	Fuel	903941T1	903941T1	
Case IH	921B	Cummins	LTA10C	Hydraulic	N9086	N9086	
Case IH	921B	Cummins	LTA10C	Hydraulic	L209303	L209303	Tank
Case IH	921B	Cummins	LTA10C	Hydraulic	S302041	S302041	Transmission
Case IH	921B	Cummins	LTA10C	Coolant	A77544	A77544	
Case IH	95XT			Lube	J908616	J908616	Standard
Case IH	95XT			Lube	J934429	J934429	Premium
Case IH	95XT			Fuel	J286503	J286503	Spin-on
Case IH	95XT			Fuel	D139225	D139225	In-line
Case IH	95XT			Air	222421A1	222421A1	Outer
Case IH	95XT			Air	222422A1	222422A1	Inner
Case IH	95XT			Hydraulic	244913A1	244913A1	Element
Case IH	95XT			Hydraulic	N9025	N9025	Return
Case IH	95XT			Hydraulic	222759A1	222759A1	Charge
Case IH	980B			Lube	A44081	A44081	
Case IH	980B			Air, Outer	S231996	S231996	S/N-620451-On
Case IH	980B			Air, Outer	L33920	L33920	To S/N-620451
Case IH	980B			Fuel	A43344	A43344	Injection Pump
Case IH	980B			Fuel	A46045	A46045	Kit
Case IH	980B			Hydraulic	S400427	S400427	S/N-6404203 ON
Case IH	980B			Hydraulic	S400427	S400427	S/N-6404203 ON Strainer
Case IH	980B			Hydraulic	S202018	S202018	Suction
Case IH	980B			Hydraulic	S202018	S202018	Suction Line
Case IH	980B			Hydraulic	S530984	S530984	Tank
Case IH	980B			Hydraulic	S140005	S140005	To S/N-6404203
Case IH	980B			Hydraulic	S233969	S233969	To S/N-6404203
Case IH	BPDHP335			Fuel	TX400031B	TX400031B	In-line
Case IH	BPDHP335			Air	TX400031A	TX400031A	
Case IH	BPDHP335			Hydraulic	98112510	98112510	In-line
Case IH	BPDHP335			Hydraulic	98010301	98010301	Suction side
Case IH	BPGHP335			Hydraulic	98112510	98112510	In-line

Case IH	BPGHP335	Hydraulic	98010301	98010301	Suction side
Case IH	CX130	Lube	J908616	J908616	Standard
Case IH	CX130	Lube	J934429	J934429	Premium
Case IH	CX130	Fuel	J931062	J931062	Spin-on
Case IH	CX130	Fuel	D139225	D139225	In-line
Case IH	CX130	Air	KRH0652	KRH0652	Outer
Case IH	CX130	Air	KRH1320	KRH1320	Inner
Case IH	CX130	Hydraulic	153233A1	153233A1	
Case IH	CX130	Hydraulic	KHJ1493	KHJ1493	Return
Case IH	CX130	Hydraulic	KNJ2567	KNJ2567	Reservoir
Case IH	CX130	Hydraulic	151552A1	151552A1	Pilot Line
Case IH	CX135SR	Lube	87405530	87405530	
Case IH	CX135SR	Lube	87409538	87409538	
Case IH	CX135SR	Fuel	368446A1	368446A1	
Case IH	CX135SR	Air	KMH0830	KMH0830	Outer
Case IH	CX135SR	Air	KMH0781	KMH0781	Inner
Case IH	CX135SR	Hydraulic	167857A1	167857A1	
Case IH	CX14	Lube	72276225	72276225	
Case IH	CX14	Fuel	72276230	72276230	
Case IH	CX14	Air	PA02P00002-3	PA02P000023	
Case IH	CX14	Hydraulic	PA33H01040P1	PA33H01040P1	
Case IH	CX160	Lube	J908616	J908616	Standard
Case IH	CX160	Lube	J934429	J934429	Premium
Case IH	CX160	Fuel	J931062	J931062	Spin-on
Case IH	CX160	Fuel	D139225	D139225	In-line
Case IH	CX160	Air	KRH0652	KRH0652	Outer
Case IH	CX160	Air	KRH1320	KRH1320	Inner
Case IH	CX160	Hydraulic	153233A1	153233A1	
Case IH	CX160	Hydraulic	KHJ1493	KHJ1493	Return
Case IH	CX160	Hydraulic	KNJ2567	KNJ2567	Reservoir
Case IH	CX160	Hydraulic	151552A1	151552A1	Pilot Line
Case IH	CX210	Lube	J942365	J942365	
Case IH	CX210	Fuel	J942533	J942533	Spin-on
Case IH	CX210	Fuel	194199A1	194199A1	In-line
Case IH	CX210	Air	KRH0652	KRH0652	Outer
Case IH	CX210	Air	KRH1320	KRH1320	Inner
Case IH	CX210	Hydraulic	153233A1	153233A1	
Case IH	CX210	Hydraulic	159274A1	159274A1	Return
Case IH	CX210	Hydraulic	KNJ1400	KNJ1400	Reservoir
Case IH	CX210	Hydraulic	151552A1	151552A1	Pilot Line
Case IH	CX225SR	Lube	86987694	86987694	
Case IH	CX225SR	Lube	288871A1	288871A1	
Case IH	CX225SR	Fuel	86992277	86992277	
Case IH	CX225SR	Air	KRH0652	KRH0652	Outer
Case IH	CX225SR	Air	KRH1320	KRH1320	Inner

Case IH	CX225SR	Hydraulic	KNJ1400	KNJ1400	
Case IH	CX240	Lube	J942365	J942365	
Case IH	CX240	Fuel	J942533	J942533	Spin-on
Case IH	CX240	Fuel	194199A1	194199A1	In-line
Case IH	CX240	Air	KRH0652	KRH0652	Outer
Case IH	CX240	Air	KRH1320	KRH1320	Inner
Case IH	CX240	Hydraulic	153233A1	153233A1	
Case IH	CX240	Hydraulic	159274A1	159274A1	Return
Case IH	CX240	Hydraulic	KNJ1400	KNJ1400	Reservoir
Case IH	CX240	Hydraulic	151552A1	151552A1	Pilot Line
Case IH	CX25	Lube	72276225	72276225	
Case IH	CX25	Fuel	72276230	72276230	
Case IH	CX25	Air	PM11P00006S00 2	PM11P00006S 002	
Case IH	CX25	Hydraulic	PM50V00012F1	PM50V00012F 1	
Case IH	CX290	Lube	J942365	J942365	
Case IH	CX290	Fuel	J942533	J942533	Spin-on
Case IH	CX290	Fuel	194199A1	194199A1	In-line
Case IH	CX290	Air	KBH0921	KBH0921	Outer
Case IH	CX290	Air	KBH0922	KBH0922	Inner
Case IH	CX290	Hydraulic	153233A1	153233A1	
Case IH	CX290	Hydraulic	159274A1	159274A1	Return
Case IH	CX290	Hydraulic	KNJ1400	KNJ1400	Reservoir
Case IH	CX290	Hydraulic	151552A1	151552A1	Pilot Line
Case IH	CX31	Lube	S19100650011	S19100650011	
Case IH	CX31	Fuel	72276230	72276230	
Case IH	CX31	Air	PY02P000073	PY02P000073	Outer
Case IH	CX31	Air	PW11P01019P1	PW11P01019P 1	Inner
Case IH	CX31	Hydraulic	PM50V00012F1	PM50V00012F 1	
Case IH	CX330	Lube	438050A1	438050A1	
Case IH	CX330	Fuel	87418199	87418199	
Case IH	CX330	Air	KSH0932	KSH0932	Outer
Case IH	CX330	Air	KSH0933	KSH0933	Inner
Case IH	CX330	Hydraulic	159282A1	159282A1	
Case IH	CX36	Lube	S19100650011	S19100650011	
Case IH	CX36	Fuel	72276230	72276230	
Case IH	CX36	Air	PY02P000073	PY02P000073	Outer
Case IH	CX36	Air	PW11P01019P1	PW11P01019P 1	Inner
Case IH	CX36	Hydraulic	PM50V00012F1	PM50V00012F 1	
Case IH	CX460	Lube	87432534	87432534	
Case IH	CX460	Lube	86987694	86987694	
Case IH	CX460	Fuel	87418199	87418199	
Case IH	CX460	Air	KTH0576	KTH0576	Outer

Case IH	CX460		Air	KTH0577	KTH0577	Inner
Case IH	CX460		Hydraulic	159282A1	159282A1	
Case IH	CX47		Lube	S19100650011	S19100650011	
Case IH	CX47		Fuel	S19100670012A	S19100670012A	
Case IH	CX47		Air	PY02P000073	PY02P000073	Outer
Case IH	CX47		Air	PW11P01019P1	PW11P01019P1	Inner
Case IH	CX47		Hydraulic	PH50V00005F1	PH50V00005F1	
Case IH	CX75SR		Lube	87409537	87409537	
Case IH	CX75SR		Fuel	368446A1	368446A1	
Case IH	CX75SR		Air	KAH1386	KAH1386	Outer
Case IH	CX75SR		Air	KAH1219	KAH1219	Inner
Case IH	CX75SR		Hydraulic	167857A1	167857A1	
Case IH	CX800		Lube	437903A1	437903A1	Main
Case IH	CX800		Lube	426436A1	426436A1	Partial
Case IH	CX800		Fuel	426430A1	426430A1	
Case IH	CX800		Air	KUH0025	KUH0025	Outer
Case IH	CX800		Air	KUH0026	KUH0026	Inner
Case IH	CX800		Hydraulic	153233A1	153233A1	
Case IH	CX800		Hydraulic	159282A1	159282A1	By-Pass
Case IH	CX800		Hydraulic	163663A1	163663A1	Hyd pump
Case IH	CX800		Hydraulic	151552A1	151552A1	Pilot Line
Case IH	CX800		Hydraulic	KUJ0160	KUJ0160	Aux Hyd
Case IH	DH4	2.1L Diesel	Lube	H412072	H412072	
Case IH	DH4	2.1L Diesel	Air, Outer	H425256	H425256	S/N-2023629 ON
Case IH	DH4	2.1L Diesel	Air, Outer	D48198	D48198	To S/N-2023629
Case IH	DH4	2.1L Diesel	Fuel Filter	6002032C91	6002032C91	Tank
Case IH	DH4	2.1L Diesel	Hydraulic	N9025	N9025	
Case IH	DH4	2.1L Diesel	Hydraulic	H584631	H584631	Steering Pump
Case IH	DH4	2.1L Diesel	Hydraulic	H335620	H335620	Suction Line
Case IH	DH4B	2.1L Diesel	Lube	H412072	H412072	
Case IH	DH4B	2.1L Diesel	Air, Outer	H425256	H425256	S/N-2023629-On
Case IH	DH4B	2.1L Diesel	Air, Outer	D48198	D48198	To S/N-2023629
Case IH	DH4B	2.1L Diesel	Fuel Filter	6002032C91	6002032C91	Tank
Case IH	DH4B	2.1L Diesel	Hydraulic	N9025	N9025	
Case IH	DH4B	2.1L Diesel	Hydraulic	H584631	H584631	Steering Pump
Case IH	DH4B	2.1L Diesel	Hydraulic	H335620	H335620	Suction Line
Case IH	DH5	188	Lube	A306696	A306696	
Case IH	DH5	188	Air, Outer	D48198	D48198	
Case IH	DH5	188	Fuel	A402081	A402081	Kit
Case IH	DH5	188	Hydraulic	H624860	H624860	Return Line
Case IH	DH5	188	Hydraulic	A42242	A42242	Steering Pump
Case IH	DH5	188	Hydraulic	H624809	H624809	Suction Line
Case IH	DH5	Case IH 188	Lube	A306696	A306696	
Case IH	DH5	Case IH 188	Air, Outer	D48198	D48198	

Case IH	DH5	Case IH	188	Fuel	A402081	A402081	Kit
Case IH	DH5	Case IH	188	Hydraulic	H624860	H624860	Return Line
Case IH	DH5	Case IH	188	Hydraulic	A42242	A42242	Steering Pump
Case IH	DH5	Case IH	188	Hydraulic	H624809	H624809	Suction Line
Case IH	DH7		219 CID	Lube	K902205	K902205	
Case IH	DH7		219 CID	Lube	J919562	J919562	S/N-44500208-On
Case IH	DH7		219 CID	Lube	A77537	A77537	To S/N-44500208
Case IH	DH7		219 CID	Air, Inner	S238647	S238647	
Case IH	DH7		219 CID	Air, Outer	S238646	S238646	
Case IH	DH7		219 CID	Air, Outer	A42274	A42274	
Case IH	DH7		219 CID	Cab Air	1970006C2	1970006C2	
Case IH	DH7		219 CID	Cab Air	1970098C1	1970098C1	
Case IH	DH7		219 CID	Fuel	3044506R93	3044506R93	
Case IH	DH7		219 CID	Fuel	J925274	J925274	Primary
Case IH	DH7		219 CID	Fuel	J903640	J903640	Secondary
Case IH	DH7		219 CID	Hydraulic	N9025	N9025	
Case IH	DH7		219 CID	Hydraulic	H402099	H402099	Screen
Case IH	DH7		219 CID	Hydraulic	S305020	S305020	Transmission
Case IH	DH7		219 CID	Coolant	A77544	A77544	
Case IH	FH4		1.8 Diesel	Lube	2036188C1	2036188C1	
Case IH	FH4		1.8 Diesel	Lube	E36534	E36534	
Case IH	FH4		1.8 Diesel	Air, Outer	D48198	D48198	
Case IH	FH4		1.8 Diesel	Fuel	6002032C91	6002032C91	
Case IH	FH4		1.8 Diesel	Fuel	3044506R93	3044506R93	
Case IH	FH4		1.8 Diesel	Hydraulic	H335620	H335620	
Case IH	FH4		2.1L Diesel	Lube	2036188C1	2036188C1	
Case IH	FH4		2.1L Diesel	Lube	H412072	H412072	
Case IH	FH4		2.1L Diesel	Air, Outer	D48198	D48198	
Case IH	FH4		2.1L Diesel	Fuel	3044506R93	3044506R93	
Case IH	FH4		2.1L Diesel	Fuel	6002032C91	6002032C91	Tank
Case IH	FH4		2.1L Diesel	Hydraulic	H335620	H335620	
Case IH	Maxi-Sneaker			Lube	2036188C1	2036188C1	3/8"
Case IH	Maxi-Sneaker			Lube	E36534	E36534	5/8"
Case IH	Maxi-Sneaker			Air, Outer	D48198	D48198	
Case IH	Maxi-Sneaker			Fuel	3044506R93	3044506R93	
Case IH	Maxi-Sneaker			Hydraulic	H340047	H340047	
Case IH	Maxi-Sneaker		1.8L Diesel	Lube	2036188C1	2036188C1	
Case IH	Maxi-Sneaker		1.8L Diesel	Air, Outer	D48198	D48198	
Case IH	Maxi-Sneaker		1.8L Diesel	Fuel	3044506R93	3044506R93	
Case IH	Maxi-Sneaker		1.8L Diesel	Hydraulic	H340047	H340047	

Case IH	Maxi-Sneaker B	Lube	N20844	N20844	
Case IH	Maxi-Sneaker B	Air, Outer	H425256	H425256	
Case IH	Maxi-Sneaker B	Fuel	H674541	H674541	
Case IH	Maxi-Sneaker B	Hydraulic	H335620	H335620	
Case IH	Maxi-Sneaker C	Lube	A46025	A46025	
Case IH	Maxi-Sneaker C	Lube	A306696	A306696	
Case IH	Maxi-Sneaker C	Lube	35034	35034	
Case IH	Maxi-Sneaker C	Lube	203528A1	203528A1	
Case IH	Maxi-Sneaker C	Air, Inner	A60742	A60742	
Case IH	Maxi-Sneaker C	Air, Inner	A60742	A60742	
Case IH	Maxi-Sneaker C	Air, Outer	A60741	A60741	
Case IH	Maxi-Sneaker C	Air, Outer	A60741	A60741	
Case IH	Maxi-Sneaker C	Air, Outer	H425256	H425256	
Case IH	Maxi-Sneaker C	Fuel	J843760	J843760	
Case IH	Maxi-Sneaker C	Fuel	A46045	A46045	Kit
Case IH	Maxi-Sneaker C	Fuel	A46045	A46045	Primary
Case IH	Maxi-Sneaker C	Fuel	72320	72320	Primary
Case IH	Maxi-Sneaker C	Fuel	G45006	G45006	Secondary
Case IH	Maxi-Sneaker C	Hydraulic	A20287	A20287	
Case IH	Maxi-Sneaker C	Hydraulic	A20287	A20287	
Case IH	Maxi-Sneaker C	Hydraulic	D202562	D202562	
Case IH	Maxi-Sneaker C	Hydraulic	34457	34457	Prior To S/N-7102001
Case IH	Maxi-Sneaker C	Hydraulic	A18789	A18789	Tank
Case IH	Maxi-Sneaker C	Hydraulic	A18789	A18789	Tank
Case IH	Maxi-Sneaker C	Hydraulic	A20220	A20220	Torque Converter
Case IH	Maxi-Sneaker C	Hydraulic	A20220	A20220	Torque Converter
Case IH	Maxi-Sneaker C	Gasket	A50735	A50735	Hydraulic
Case IH	Maxi-Sneaker C	Gasket	A50735	A50735	Hydraulic

Sneaker C							
Case IH	Mini-Sneaker B	Hatz		Air, Outer	D48198	D48198	
Case IH	Mini-Sneaker B	Hatz		Fuel	D59949	D59949	
Case IH	Mini-Sneaker B	Hatz		Hydraulic	H335620	H335620	
Case IH	Mini-Sneaker N63	Onan		Hydraulic	H340047	H340047	
Case IH	Mini-Sneaker P63			Hydraulic	H340047	H340047	
Case IH	Mini-Sneaker T63			Hydraulic	H340047	H340047	
Case IH	TF1000		207	Lube	A306696	A306696	
Case IH	TF1000		207	Air, Outer	A42274	A42274	
Case IH	TF1000		207	Fuel	A402081	A402081	Primary
Case IH	TF1000		207	Hydraulic	S220566	S220566	
Case IH	TF300			Hydraulic	H340054	H340054	
Case IH	TF300	Teledyne	TJD	Hydraulic	H340054	H340054	
Case IH	TF700			Hydraulic	H340054	H340054	
Case IH	TF700			Hydraulic	H402099	H402099	Suction
Case IH	W10			Lube	A20822	A20822	
Case IH	W10			Air, Outer	A40903	A40903	
Case IH	W10			Fuel	A57228	A57228	
Case IH	W10			Fuel	A22001	A22001	Primary
Case IH	W10			Fuel	A7627	A7627	Secondary
Case IH	W10			Hydraulic	A20287	A20287	
Case IH	W10			Hydraulic	A20220	A20220	Torque Converter
Case IH	W10			Gasket	A50735	A50735	Hydraulic
Case IH	W10B			Lube	A20822	A20822	
Case IH	W10B			Air, Outer	A60741	A60741	
Case IH	W10B			Air, Outer	A60742	A60742	
Case IH	W10B			Fuel	A57228	A57228	
Case IH	W10B			Fuel	A22001	A22001	Primary
Case IH	W10B			Fuel	A7627	A7627	Secondary
Case IH	W10B			Hydraulic	A20287	A20287	
Case IH	W10B			Hydraulic	A50735	A50735	
Case IH	W10C			Lube	A46025	A46025	
Case IH	W10C			Air, Inner	A60742	A60742	
Case IH	W10C			Air, Outer	A60741	A60741	
Case IH	W10C			Fuel	A46045	A46045	Kit
Case IH	W10C			Hydraulic	A20287	A20287	
Case IH	W10C			Hydraulic	A18789	A18789	Tank
Case IH	W10C			Hydraulic	A20220	A20220	Torque Converter
Case IH	W10C			Gasket	A50735	A50735	Hydraulic
Case IH	W10E			Lube	A306696	A306696	
Case IH	W10E			Air, Inner	A60742	A60742	
Case IH	W10E			Air, Outer	A60741	A60741	

Case IH	W10E			Fuel	A46045	A46045	Primary
Case IH	W10E			Hydraulic	A20287	A20287	
Case IH	W10E			Hydraulic	A18789	A18789	Tank
Case IH	W10E			Hydraulic	A20220	A20220	Torque Converter
Case IH	W10E			Gasket	A50735	A50735	Hydraulic
Case IH	W11			Lube	A306696	A306696	
Case IH	W11			Air, Outer	A42274	A42274	
Case IH	W11			Cab Air	D80648	D80648	
Case IH	W11			Fuel	A402081	A402081	Kit
Case IH	W11			Hydraulic	D80538	D80538	
Case IH	W11			Hydraulic	L76532	L76532	Tank
Case IH	W11B	Cummins	4B3.9	Lube	J908650	J908650	
Case IH	W11B	Cummins	4B3.9	Air, Inner	A603291	A603291	
Case IH	W11B	Cummins	4B3.9	Air, Outer	A603290	A603290	
Case IH	W11B	Cummins	4B3.9	Cab Air	D80648	D80648	
Case IH	W11B	Cummins	4B3.9	Fuel	J925274	J925274	Primary
Case IH	W11B	Cummins	4B3.9	Fuel	J903640	J903640	Secondary
Case IH	W11B	Cummins	4B3.9	Hydraulic	D80538	D80538	
Case IH	W11B	Cummins	4B3.9	Hydraulic	L76532	L76532	Tank
Case IH	W11B	Cummins	4B3.9	Hydraulic	D80548	D80548	Transmission
Case IH	W12			Lube	A20822	A20822	
Case IH	W12			Air, Outer	A40903	A40903	
Case IH	W12			Fuel	A57228	A57228	
Case IH	W12			Fuel	A22001	A22001	Primary
Case IH	W12			Fuel	A7627	A7627	Secondary
Case IH	W12			Hydraulic	A20287	A20287	
Case IH	W12			Hydraulic	A20220	A20220	Torque Converter
Case IH	W12			Gasket	A50735	A50735	Hydraulic
Case IH	W14	Case IH	336B	Lube	A44081	A44081	S/N-10018987-On
Case IH	W14	Case IH	336B	Lube	A306696	A306696	To S/N-10018987
Case IH	W14	Case IH	336B	Air, Inner	A43735	A43735	
Case IH	W14	Case IH	336B	Air, Outer	A43734	A43734	
Case IH	W14	Case IH	336B	Cab Air	D80562	D80562	
Case IH	W14	Case IH	336B	Fuel	A43344	A43344	Injection Pump
Case IH	W14	Case IH	336B	Fuel	N6000	N6000	Injection Pump
Case IH	W14	Case IH	336B	Fuel	A46045	A46045	Kit
Case IH	W14	Case IH	336B	Hydraulic	L50384	L50384	Tank
Case IH	W14	Case IH	336B	Hydraulic	A62034	A62034	Transmission
Case IH	W14 Feedlot	Case IH	336B	Lube	A44081	A44081	S/N-10018987-On
Case IH	W14 Feedlot	Case IH	336B	Lube	A306696	A306696	To S/N-10018987
Case IH	W14 Feedlot	Case IH	336B	Air, Inner	A43735	A43735	
Case IH	W14 Feedlot	Case IH	336B	Air, Outer	A43734	A43734	
Case IH	W14 Feedlot	Case IH	336B	Cab Air	D80562	D80562	
Case IH	W14 Feedlot	Case IH	336B	Fuel	A43344	A43344	Injection Pump
Case IH	W14 Feedlot	Case IH	336B	Fuel	N6000	N6000	Injection Pump

Case IH	W14 Feedlot	Case IH	336B	Fuel	A46045	A46045	Kit
Case IH	W14 Feedlot	Case IH	336B	Hydraulic	L50384	L50384	Tank
Case IH	W14 Feedlot	Case IH	336B	Hydraulic	A62034	A62034	Transmission
Case IH	W14B	Case IH	A336BD	Lube	J908640	J908640	
Case IH	W14B	Case IH	A336BD	Air, Inner	N8403	N8403	
Case IH	W14B	Case IH	A336BD	Air, Outer	D56453	D56453	
Case IH	W14B	Case IH	A336BD	Cab Air	D80562	D80562	
Case IH	W14B	Case IH	A336BD	Fuel	J925274	J925274	Primary
Case IH	W14B	Case IH	A336BD	Fuel	J903640	J903640	Secondary
Case IH	W14B	Case IH	A336BD	Hydraulic	N9086	N9086	
Case IH	W14B	Case IH	A336BD	Hydraulic	D306735	D306735	Transmission
Case IH	W14C	Cummins	6B5.9	Lube	J908640	J908640	
Case IH	W14C	Cummins	6B5.9	Air, Inner	N8403	N8403	
Case IH	W14C	Cummins	6B5.9	Air, Outer	D56453	D56453	
Case IH	W14C	Cummins	6B5.9	Cab Air	D80562	D80562	
Case IH	W14C	Cummins	6B5.9	Fuel	J925274	J925274	Primary
Case IH	W14C	Cummins	6B5.9	Fuel	J903640	J903640	Secondary
Case IH	W14C	Cummins	6B5.9	Hydraulic	N9086	N9086	
Case IH	W14C	Cummins	6B5.9	Hydraulic	D306735	D306735	Transmission
Case IH	W14H	Case IH	336B	Lube	A44081	A44081	S/N-10018987-On
Case IH	W14H	Case IH	336B	Lube	A306696	A306696	To S/N-10018987
Case IH	W14H	Case IH	336B	Air, Inner	A43735	A43735	
Case IH	W14H	Case IH	336B	Air, Outer	A43734	A43734	
Case IH	W14H	Case IH	336B	Fuel	A43344	A43344	Injection Pump
Case IH	W14H	Case IH	336B	Fuel	N6000	N6000	Injection Pump
Case IH	W14H	Case IH	336B	Fuel	A46045	A46045	Kit
Case IH	W14H	Case IH	336B	Hydraulic	L50384	L50384	Tank
Case IH	W14H	Case IH	336B	Hydraulic	A62034	A62034	Transmission
Case IH	W18	Case IH	401B	Lube	A75294	A75294	
Case IH	W18	Case IH	401B	Lube	A64453	A64453	S/N-2523871-2570670
Case IH	W18	Case IH	401B	Air, Inner	A60742	A60742	
Case IH	W18	Case IH	401B	Air, Outer	A60741	A60741	
Case IH	W18	Case IH	401B	Air, Outer	A43734	A43734	
Case IH	W18	Case IH	401B	Air, Outer	A43735	A43735	
Case IH	W18	Case IH	401B	Cab Air	D80562	D80562	
Case IH	W18	Case IH	401B	Fuel	A40330	A40330	Injection Pump
Case IH	W18	Case IH	401B	Fuel	A43344	A43344	Injection Pump
Case IH	W18	Case IH	401B	Fuel	A47305	A47305	Kit
Case IH	W18	Case IH	401B	Fuel	N6000	N6000	S/N-9203300 & After
Case IH	W18	Case IH	401B	Hydraulic	34457	34457	
Case IH	W18	Case IH	401B	Hydraulic	L50384	L50384	Tank
Case IH	W18	Case IH	401B	Hydraulic	A62034	A62034	Transmission
Case IH	W18	Case IH	401B	Hydraulic	N9960	N9960	Transmission
Case IH	W18B			Lube	A44081	A44081	
Case IH	W18B			Air, Inner	A43735	A43735	

Case IH	W18B	Air, Outer	A43734	A43734	
Case IH	W18B	Cab Air	D80562	D80562	
Case IH	W18B	Fuel	A43344	A43344	Injection Pump
Case IH	W18B	Fuel	N6000	N6000	Injection Pump
Case IH	W18B	Fuel	A46045	A46045	Kit
Case IH	W18B	Fuel	A46045	A46045	Primary
Case IH	W18B	Hydraulic	A45625	A45625	
Case IH	W18B	Hydraulic	A45625	A45625	Kit
Case IH	W18B	Hydraulic	L104990	L104990	Tank
Case IH	W18B	Hydraulic	A62034	A62034	Transmission
Case IH	W20	Lube	A64453	A64453	S/N-2523871-2570670
Case IH	W20	Lube	A75294	A75294	To S/N-2523871 & 2570670-On
Case IH	W20	Cab Air	D80562	D80562	
Case IH	W20	Air, Inner	A43735	A43735	S/N-9107854-On
Case IH	W20	Air, Outer	A43734	A43734	S/N-9107854-On
Case IH	W20	Air, Inner	A60741	A60741	To S/N-9107854
Case IH	W20	Air, Outer	A60742	A60742	To S/N-9107854
Case IH	W20	Fuel	A43344	A43344	Injection Pump
Case IH	W20	Fuel	A46045	A46045	Primary
Case IH	W20	Fuel	N6000	N6000	S/N-9203300-On
Case IH	W20	Fuel	A40330	A40330	To S/N-9203300
Case IH	W20	Hydraulic	L50384	L50384	S/N-9107854-On
Case IH	W20	Hydraulic	A62034	A62034	S/N-9203300 & After Transmission
Case IH	W20	Hydraulic	A62034	A62034	S/N-9203300-On Transmission
Case IH	W20	Hydraulic	34457	34457	To S/N-9107854 Tank
Case IH	W20	Hydraulic	N9960	N9960	To S/N-9203300 Transmission
Case IH	W20B	Lube	A75294	A75294	S/N 9127506 ON
Case IH	W20B	Air, Inner	A43735	A43735	S/N 9127506 ON
Case IH	W20B	Air, Outer	A43734	A43734	S/N 9127506 ON
Case IH	W20B	Cab Air	D80562	D80562	S/N 9127506 ON
Case IH	W20B	Fuel	A43344	A43344	Injection Pump S/N 9127506 ON
Case IH	W20B	Fuel	N6000	N6000	Injection Pump S/N 9127506 ON
Case IH	W20B	Fuel	A46045	A46045	Primary S/N 9127506 ON
Case IH	W20B	Hydraulic	L50384	L50384	Tank S/N 9127506 ON
Case IH	W20B	Hydraulic	A62034	A62034	Transmission S/N 9127506 ON
Case IH	W20C	Lube	A44081	A44081	
Case IH	W20C	Air, Inner	A43735	A43735	
Case IH	W20C	Air, Outer	A43734	A43734	
Case IH	W20C	Cab Air	D80562	D80562	
Case IH	W20C	Fuel	A43344	A43344	Injection Pump
Case IH	W20C	Fuel	N6000	N6000	Injection Pump
Case IH	W20C	Fuel	A46045	A46045	Kit
Case IH	W20C	Hydraulic	A45625	A45625	Kit
Case IH	W20C	Hydraulic	L104990	L104990	Tank
Case IH	W20C	Hydraulic	A62034	A62034	Transmission

Case IH	W20C		Hydraulic	L36242	L36242	Transmission
Case IH	W24		Lube	A75294	A75294	
Case IH	W24		Air, Inner	L32520	L32520	
Case IH	W24		Air, Outer	L32520	L32520	
Case IH	W24		Fuel	A40330	A40330	Injection Pump
Case IH	W24		Fuel	A43344	A43344	Injection Pump
Case IH	W24		Fuel	A46045	A46045	Primary
Case IH	W24		Hydraulic	L47208	L47208	
Case IH	W24		Hydraulic	A62034	A62034	S/N-9105209-On Trans.
Case IH	W24		Hydraulic	34457	34457	Tank
Case IH	W24		Hydraulic	A20220	A20220	To S/N-9105209 Trans.
Case IH	W24B		Lube	A75294	A75294	S/N-2572020-On
Case IH	W24B		Lube	A64453	A64453	To S/N-2572020
Case IH	W24B		Cab Air	D80562	D80562	
Case IH	W24B		Air, Inner	A43735	A43735	S/N-9200798
Case IH	W24B		Air, Outer	A43734	A43734	S/N-9200798-On
Case IH	W24B		Air, Inner	L32520	L32520	To S/N-9200798
Case IH	W24B		Air, Outer	L32520	L32520	To S/N-9200798
Case IH	W24B		Fuel	A43344	A43344	Injection Pump
Case IH	W24B		Fuel	N6000	N6000	Injection Pump
Case IH	W24B		Fuel Kit Engine	A46045	A46045	Kit
Case IH	W24B		Fuel	A46045	A46045	Primary
Case IH	W24B		Hydraulic	L47208	L47208	
Case IH	W24B		Hydraulic	L50384	L50384	Tank
Case IH	W24B		Hydraulic	A62034	A62034	Transmission
Case IH	W24C		Lube	A75294	A75294	
Case IH	W24C		Air, Inner	A43735	A43735	
Case IH	W24C		Air, Outer	A43734	A43734	
Case IH	W24C		Cab Air	D80562	D80562	
Case IH	W24C		Fuel	A43344	A43344	Injection Pump
Case IH	W24C		Fuel	N6000	N6000	Injection Pump
Case IH	W24C		Fuel	A46045	A46045	Kit
Case IH	W24C		Hydraulic	L47208	L47208	
Case IH	W24C		Hydraulic	A45625	A45625	LDR.Circuit
Case IH	W24C		Hydraulic	L104990	L104990	Tank S/N-9303772-On
Case IH	W24C		Hydraulic	L50384	L50384	Tank To S/N-9303772
Case IH	W24C		Hydraulic	A62034	A62034	Transmission
Case IH	W26	Detroit Diesel	Lube	L32030	L32030	
Case IH	W26	Detroit Diesel	Fuel	L32040	L32040	Secondary
Case IH	W26	Detroit Diesel	Hydraulic	L47208	L47208	
Case IH	W26	Detroit Diesel	Hydraulic	34457	34457	Tank
Case IH	W26	Detroit Diesel	Hydraulic	A20220	A20220	Transmission
Case IH	W26B	Case IH 504	Lube	A62423	A62423	
Case IH	W26B	Case IH 504	Lube	A64453	A64453	

Case IH	W26B	Case IH	504	Air, Inner	L32942	L32942	
Case IH	W26B	Case IH	504	Air, Outer	L32943	L32943	
Case IH	W26B	Case IH	504	Fuel	A40330	A40330	Injection Pump
Case IH	W26B	Case IH	504	Fuel	A46045	A46045	Kit
Case IH	W26B	Case IH	504	Hydraulic	34457	34457	
Case IH	W26B	Case IH	504	Hydraulic	L47208	L47208	
Case IH	W26B	Case IH	504	Hydraulic	L72877	L72877	Tank
Case IH	W26B	Case IH	504	Hydraulic	A62034	A62034	Transmission
Case IH	W26LF	Case IH	504	Lube	A62423	A62423	
Case IH	W26LF	Case IH	504	Lube	A64453	A64453	
Case IH	W26LF	Case IH	504	Air, Inner	L32942	L32942	
Case IH	W26LF	Case IH	504	Air, Outer	L32943	L32943	
Case IH	W26LF	Case IH	504	Fuel	A40330	A40330	Injection Pump
Case IH	W26LF	Case IH	504	Fuel	A43344	A43344	Injection Pump
Case IH	W26LF	Case IH	504	Fuel	A47305	A47305	Kit
Case IH	W26LF	Case IH	504	Hydraulic	34457	34457	
Case IH	W26LF	Case IH	504	Hydraulic	L47208	L47208	
Case IH	W26LF	Case IH	504	Hydraulic	L72877	L72877	
Case IH	W26LF	Case IH	504	Hydraulic	A62034	A62034	Transmission
Case IH	W3			Lube	A306696	A306696	
Case IH	W3			Hydraulic	G20203	G20203	
Case IH	W30	Case IH	504BDT	Lube	A44081	A44081	
Case IH	W30	Case IH	504BDT	Air, Inner	S238647	S238647	
Case IH	W30	Case IH	504BDT	Air, Outer	S238646	S238646	
Case IH	W30	Case IH	504BDT	Fuel	A44068	A44068	Primary
Case IH	W30	Case IH	504BDT	Hydraulic	A45625	A45625	
Case IH	W30	Case IH	504BDT	Hydraulic	L104990	L104990	Tank
Case IH	W30	Case IH	504BDT	Hydraulic	L36242	L36242	Transmission
Case IH	W36			Lube	A77537	A77537	S/N 17754000-ON
Case IH	W36			Air, Inner	E406252	E406252	S/N 17754000-ON
Case IH	W36			Air, Outer	E406251	E406251	S/N 17754000-ON
Case IH	W36			Cab Air	D80562	D80562	S/N 17754000-ON
Case IH	W36			Fuel	J925274	J925274	Primary S/N 17754000-ON
Case IH	W36			Fuel	J903640	J903640	Secondary S/N 17754000-ON
Case IH	W36			Hydraulic	A45625	A45625	S/N 17754000-ON
Case IH	W36			Hydraulic	A45625	A45625	Kit S/N 17754000-ON
Case IH	W36			Hydraulic	E406803	E406803	Transfer Pump S/N 17754000-ON
Case IH	W36			Hydraulic	D52932	D52932	Transmission S/N 17754000-ON
Case IH	W36			Coolant	A77544	A77544	S/N 17754000-

							ON
Case IH	W36		Lube	A44081	A44081		TO-S/N 17754000
Case IH	W36		Air, Inner	A44805	A44805		TO-S/N 17754000
Case IH	W36		Air, Outer	A44804	A44804		TO-S/N 17754000
Case IH	W36		Cab Air	D80562	D80562		TO-S/N 17754000
Case IH	W36		Fuel	A44068	A44068	Kit	TO-S/N 17754000
Case IH	W36		Hydraulic	A45625	A45625		TO-S/N 17754000
Case IH	W36		Hydraulic	L104990	L104990	Tank	TO-S/N 17754000
Case IH	W36		Hydraulic	L72877	L72877	Tank	TO-S/N 17754000
Case IH	W4	1.8L Diesel	Lube	2036188C1	2036188C1	3/8"	
Case IH	W4	1.8L Diesel	Lube	E36534	E36534	5/8"	
Case IH	W4	1.8L Diesel	Air, Outer	D48198	D48198		
Case IH	W4	1.8L Diesel	Fuel	3044506R93	3044506R93		
Case IH	W4	1.8L Diesel	Hydraulic	H335620	H335620		
Case IH	W4	2.1L Diesel	Lube	H412072	H412072		
Case IH	W4	2.1L Diesel	Air, Outer	D48198	D48198		
Case IH	W4	2.1L Diesel	Fuel	H659524	H659524	Kit	
Case IH	W4	2.1L Diesel	Fuel	6002032C91	6002032C91	Tank	
Case IH	W4	2.1L Diesel	Hydraulic	H335620	H335620		
Case IH	W5		Lube	A36206	A36206		
Case IH	W5		Hydraulic	A27377	A27377		
Case IH	W5A		Lube	A306696	A306696		
Case IH	W5A		Fuel	A52046	A52046		
Case IH	W5A		Hydraulic	A27377	A27377		
Case IH	W7		Lube	A23075	A23075		
Case IH	W7		Air, Inner	A60742	A60742		
Case IH	W7		Air, Outer	A60741	A60741		
Case IH	W7		Air, Outer	A46045	A46045		
Case IH	W7		Fuel	A22001	A22001	Primary	
Case IH	W7		Fuel	A7627	A7627	Secondary	
Case IH	W7		Hydraulic	A33487	A33487		
Case IH	W7		Hydraulic	A60420	A60420	Tank	
Case IH	W7		Hydraulic	A20220	A20220	Torque Converter	
Case IH	W7		Gasket	A60425	A60425	Hydraulic	
Case IH	W7C		Lube	A23075	A23075		
Case IH	W7C		Air, Inner	A60742	A60742		
Case IH	W7C		Air, Outer	A60741	A60741		
Case IH	W7C		Fuel	A46045	A46045	Primary	
Case IH	W7C		Hydraulic	A33487	A33487		
Case IH	W7C		Hydraulic	A60425	A60425	Gasket	

Case IH	W7C	Hydraulic	A60420	A60420	Tank
Case IH	W7C	Hydraulic	A20220	A20220	Torque Converter
Case IH	W7E	Lube	A306696	A306696	
Case IH	W7E	Air, Inner	A60742	A60742	
Case IH	W7E	Air, Outer	A60741	A60741	
Case IH	W7E	Fuel	A46045	A46045	Primary
Case IH	W7E	Hydraulic	A33487	A33487	
Case IH	W7E	Hydraulic	A60440	A60440	Return
Case IH	W7E	Hydraulic	A60420	A60420	Tank
Case IH	W7E	Hydraulic	A20220	A20220	Torque Converter
Case IH	W7E	Gasket	A60425	A60425	Hydraulic
Case IH	W8B	Lube	A46025	A46025	S/N-2207547-On
Case IH	W8B	Lube	A20822	A20822	To S/N-2207594
Case IH	W8B	Air, Inner	A60742	A60742	
Case IH	W8B	Air, Outer	A60741	A60741	
Case IH	W8B	Air, Outer	A46045	A46045	
Case IH	W8B	Fuel	A57228	A57228	
Case IH	W8B	Fuel	A22001	A22001	Primary
Case IH	W8B	Fuel	A7627	A7627	Secondary
Case IH	W8B	Hydraulic	A20287	A20287	
Case IH	W8B	Hydraulic	A50784	A50784	
Case IH	W8B	Hydraulic	A20220	A20220	Torque Converter
Case IH	W8C	Lube	A46025	A46025	
Case IH	W8C	Air, Inner	A60742	A60742	
Case IH	W8C	Air, Outer	A60741	A60741	
Case IH	W8C	Fuel	A46045	A46045	Primary
Case IH	W8C	Hydraulic	A20287	A20287	
Case IH	W8C	Hydraulic	A18789	A18789	Tank
Case IH	W8C	Hydraulic	A20220	A20220	Torque Converter
Case IH	W8C	Gasket	A50735	A50735	Hydraulic
Case IH	W9A	Lube	A23075	A23075	
Case IH	W9A	Air, Outer	A40903	A40903	
Case IH	W9A	Fuel	A57228	A57228	
Case IH	W9A	Fuel	A22001	A22001	Primary
Case IH	W9A	Fuel	A7627	A7627	Secondary
Case IH	W9A	Hydraulic	A20287	A20287	
Case IH	W9A	Hydraulic	A20220	A20220	Torque Converter
Case IH	W9A	Gasket	A50735	A50735	Hydraulic
Case IH	W9B	Lube	A20822	A20822	
Case IH	W9B	Air, Inner	A60742	A60742	
Case IH	W9B	Air, Outer	A60741	A60741	
Case IH	W9B	Fuel	A57228	A57228	
Case IH	W9B	Fuel	A22001	A22001	Primary
Case IH	W9B	Fuel	A7627	A7627	Secondary
Case IH	W9B	Hydraulic	A20287	A20287	

Case IH	W9B	Hydraulic	A20220	A20220	Torque Converter
Case IH	W9B	Gasket	A50735	A50735	Hydraulic